










Original	Replacement
	 Power
	 Mute / Dimmer
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 D.Menu / Top
	 Back / Return
	 Picture / Format
	 Sound / Title
	 Sleep / Timer

Original	Replacement
	 Menu / Home
	 AV / Input / RDS
	 Up
	 Left
	 OK
	 Right
	 Down
	 Exit / Cancel / Clear
	 Display / Media
	 Vol+
	 Vol-
	 Info / Angle
	 Smart / List
	 CH+ / Page+
	 CH- / Page-
	 Fav / Marker / PC
	 Rec / Rec Mode






Original		Replacement		Original		Replacement	
	Freeze		Pause / Step / Freeze		Green		Green / APP / Repeat
	Guide		Guide / EPG / -/--		Yellow		Yellow / YouTube / Repeat
	<<		<< / Tune-		Cyan		Blue / Prime Video / Random
	>> / Aspect		>> / Tune+				
	>> / Aspect		Shift + Picture / Format				
	I<< / Cancel		I<< / Preset-				
	I<< / Cancel		Shift + Exit / Cancel / Clear				
	>>I / Sub.PG		>>I / Preset+				
	Stop / Index		Stop / Hold				
	Play/Pause / Timeshift		Play / Slow				
	Tv/Radio		TV/Radio /				
	Subtitle		Subtitle / EQ				
	Reveal		Eject / Surround				
	Size		Zoom / Size				
	Hold		Shift + Stop /				
	Text		Text / Goto				
	Red		Red / Netflix / Search				


























Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	DTV/ATV		D.Menu / Top
	Recall		Back / Return
	P.Mode		Picture / Format
	S.Mode		Sound / Title
	Sleep		Sleep / Timer
	Menu		Menu / Home
	Source		AV / Input / RDS
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Exit		Exit / Cancel / Clear
	Display		Display / Media
	Vol+		Vol+
	Vol-		Vol-
	MTS		Info / Angle
	Rec List		Smart / List
	CH+		CH+ / Page+
	CH-		CH- / Page-
	FAV/List		Fav / Marker / PC
	Rec		Rec / Rec Mode





Original	Replacement
 Freeze	 Pause / Step / Freeze
 Guide	 Guide / EPG / -/--
 <<	 << / Tune-
 >> / Aspect	 >> / Tune+
 >> / Aspect	 Shift + Picture / Format
 << / Cancel	 << / Preset-
 << / Cancel	 Shift + Exit / Cancel / Clear
 >> / Sub.PG	 >> / Preset+
 Stop / Index	 Stop / Hold
 Play/Pause / Timeshift	 Play / Slow
 Tv/Radio	 TV/Radio /
 Subtitle	 Subtitle / EQ
 Reveal	 Eject / Surround
 Size	 Zoom / Size
 Hold	 Shift + Stop /
 Text	 Text / Goto
 Red	 Red / Netflix / Search

Original	Replacement
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Cyan	 Blue / Prime Video / Random

