



Original		Replacement		Original		Replacement	
	Power		Power		Vol-		Vol -
	PP		Pre Ch		Up		Up
	Mute		Mute		Down		Down
	I-II		Dual		Right		Right
	P<P		Back		Left		Left
	-/--		Guide		M		Ok
	1		1		PR+		Ch +
	2		2		PR-		Ch -
	3		3		M		Menu
	4		4		Red/Sound		Red
	5		5		Green/Picture		Green
	6		6		Yellow/Feature		Yellow
	7		7		Blue/Install		Blue
	8		8		TV		TV/R
	9		9		AV		AV
	0		0		[≡]		Text
	Vol+		Vol +		[≡o]		Smart



