













































































Original	Replacement	Original	Replacement
 Power	 Power	 Pop Up/Menu	 Menu
 Open/Close	 Eject	 <<	 <<
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 >>	 >>
 4	 4	 I<<	 I<<
 5	 5	 Stop	 Stop
 6	 6	 >>I	 >>I
 7	 7	 Setting	 Options
 8	 8	 Exit	 Exit
 9	 9	 Step/Slow	 AV
 0	 0	 Up	 Up
 Goto	 Guide	 Down	 Down
 Clear	 Shift + Exit	 Right	 Right
 OSC	 Media	 Left	 Left
 Top Menu	 Shift + Menu	 OK	 Ok
 PIP	 3D	 Return	 Back





Original		Replacement		Original		Replacement	
	Home		Smart				
	Red/Program		Red				
	Green/Digest		Green				
	Yellow/Zoom		Yellow				
	Blue/Bookmark		Blue				
	Sub		Subt				
	Audio		Dual				
	2nd. Audio	 + 	Shift + Dual				
	Angle		Pre Ch				
	A-B		List				
	Repeat		Text				
	Display		Info				

