





































































Original	Replacement	Original	Replacement
 Power	 Power	 +10	 Pre Ch
 Open/Close	 Eject	 Mute	 Mute
 Subtitle	 Subt	 N/P	 Format
 Angle/Del	 Exit	 PBC	 3D
 Language	 Dual	 OSD	 Smart
 Return	 Back	 Setup	 Options
 Time	 Shift + AV	 Title/TTX	 Text
 1	 1	 Menu	 Menu
 2	 2	 Prog/EPG	 Guide
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 Enter	 Ok
 8	 8	 Play	 Play
 9	 9	 Stop	 Stop
 0/10	 0	 Pause	 Pause



