



Original	Replacement
Power On	Power
Power Off	Shift + Power
Zone Device On	Smart
Zone Device Off	Shift + Smart
Net/USB	Shift + 1
iPod	Shift + 2
DVD	Shift + 3
BD	Shift + 4
Tuner/DTU	Shift + 5
Dock	Shift + 6
SAT TU	Shift + 7
SAT/CBL	Shift + 8
Game	Shift + 9
V.AUX	Shift + Guide
Phono	Shift + 0
CD	Shift + Pre Ch
DVR	Blue

Original	Replacement
TV	Shift + Media
Monitor Select	Media
Quick Select 1	Red
Quick Select 2 (SAT/CBL)	Green
Quick Select 3 (Dock)	Yellow
CH+	Ch +
CH-	Ch -
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Source Select	AV
Menu	Menu
CH Level/Top	Info
Search/Setup	Options
Return	Back
Up	Up
Down	Down































Original	Replacement	Original	Replacement
	Right		Right
	Left		Left
	Enter		Ok
	<</Band		<<
	Play		Play
	>>/Mode		>>
	I<</Tuning-		I<<
	Pause		Pause
	Stop		Stop
	>>I/Tuning+		>>I
	Multeq		Subt
	Dyn EQ/Vol		Text
	A-DSX		TV/R
	Restorer		Exit
	Standard		Dual
	D/ST		Format
	Simulation		3D
	Pure		Pre Ch
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10/Memory		Guide
	Shift/Link Menu		D. Menu
	Power Tv	 + 	Shift + TV/R
	Input Tv	 + 	Shift + AV
	Sleep		Sleep
	Party		List






























Original	Replacement
 Power On	 Power
 Power Off	 Shift + Power
 Zone Device On	 Smart
 Zone Device Off	 Shift + Smart
 Net/USB	 Shift + 1
 iPod	 Shift + 2
 DVD	 Shift + 3
 BD	 Shift + 4
 Tuner/DTU	 Shift + 5
 Dock	 Shift + 6
 SAT TU	 Shift + 7
 SAT/CBL	 Shift + 8
 Game	 Shift + 9
 V.AUX	 Shift + Guide
 Phono	 Shift + 0
 CD	 Pre Ch
 DVR	 Blue

Original	Replacement
 TV	 Media
 Quick Select 1	 Red
 Quick Select 2 (SAT/CBL)	 Green
 Quick Select 3 (Dock)	 Yellow
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Menu	 Menu
 CH Level/Top	 Info
 Search/Setup	 Options
 Return	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Original	Replacement
 Power On	 Power
 Power Off	 Shift + Power
 Zone Device On	 Smart
 Zone Device Off	 Shift + Smart
 Net/USB	 Shift + 1
 iPod	 Shift + 2
 DVD	 Shift + 3
 BD	 Shift + 4
 Tuner/DTU	 Shift + 5
 Dock	 Shift + 6
 SAT TU	 Shift + 7
 SAT/CBL	 Shift + 8
 Game	 Shift + 9
 V.AUX	 Shift + Guide
 Phono	 Shift + 0
 CD	 Pre Ch
 DVR	 Blue

Original	Replacement
 TV	 Media
 Quick Select 1	 Red
 Quick Select 2 (SAT/CBL)	 Green
 Quick Select 3 (Dock)	 Yellow
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Menu	 Menu
 CH Level/Top	 Info
 Search/Setup	 Options
 Return	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left




































Original	Replacement
 Power On	 Power
 Power Off	 Shift + Power
 Zone Device On	 Smart
 Zone Device Off	 Shift + Smart
 NET/USB	 Shift + 1
 iPod	 Shift + 2
 DVD	 Shift + 3
 BD	 Shift + 4
 Tuner/DTU	 Shift + 5
 Dock	 Shift + 6
 SAT TU	 Shift + 7
 SAT/CBL	 Shift + 8
 Game	 Shift + 9
 V.AUX	 Shift + Guide
 Phono	 Shift + 0
 CD	 Pre Ch
 DVR	 Blue

Original	Replacement
 TV	 Media
 Quick Select 1	 Red
 Quick Select 2 (SAT/CBL)	 Green
 Quick Select 3 (Dock)	 Yellow
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Search/Setup	 Options
 <</Band	 <<
 Play	 Play
 >>/Mode	 >>
 I<</Tuning-	 I<<
 Pause	 Pause
 Stop	 Stop
 >>I/Tuning+	 >>I





	Original	Replacement	Original	Replacement
	1			
	2			
	3			
	4			
	5			
	6			
	7			
	8			
	9			
	0			
	+10/Memory			
	Power Tv			
	Shift/Link Menu			
	Input Tv			
	Sleep			
	Party	