



Original	Replacement	Original	Replacement
 Power	 Power	 --	 Guide / EPG / -/--
 Up / P+	 Up	 0	 0
 Up / P+	 CH+ / Page+	 P < P	 Fav / Marker / PC
 Menu	 Menu / Home	 PP	 Back / Return
 Left	 Left	 Vol+	 Vol+
 Right	 Right	 I-II	 Audio / Lang I/II
 Down / P-	 Down	 Mute	 Mute / Dimmer
 Down / P-	 CH- / Page-	 Vol-	 Vol-
 1	 1	 Info	 Info / Angle
 2	 2	 Red	 Red / Netflix / Search
 3	 3	 Green	 Green / APP / Repeat
 4	 4	 Yellow	 Yellow / YouTube / Repeat
 5	 5	 Blue	 Blue / Prime Video / Random
 6	 6	 [TV]	 Shift + 1
 7	 7	 [TV]	 TV/Radio /
 8	 8	 [AV]	 AV / Input / RDS
 9	 9	 [≡]	 Text / Goto





Original	Replacement	Original	Replacement
	[≡☉] EQ Subtitle / EQ		
	[/≡] FORMAT Picture / Format		
	[≡X] CLEAR EXIT / CANCEL Exit / Cancel / Clear		
	[≡↕] SIZE ZOOM Zoom / Size		
	[≡?] MEDIA DISPLAY Display / Media		
	[≡i] LIST SMART Smart / List		

Original	Replacement	Original	Replacement





Original	Replacement	Original	Replacement
	Power		Power
	Up / P+		Up
	Up / P+		CH+ / Page+
	Menu		Menu / Home
	Left		Left
	Select		OK
	Right		Right
	Down / P-		CH- / Page-
	Down / P-		Down
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	+10		Guide / EPG / -/-
	0		0
	Repeat		Green / APP / Repeat
	Search		Red / Netflix / Search
	A→B		Yellow / YouTube / Repeat
	Display		Display / Media
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Zoom		Zoom / Size
	Prog		TV/Radio /
	C		Blue / Prime Video / Random
	Angle		Info / Angle
	Return		Back / Return
	Time		Sleep / Timer
	<<		<< / Tune-
	>>		>> / Tune+








































































	Original	Replacement	Original	Replacement
		I<< / Preset-		
		>>I / Preset+		
		Play / Slow		
		Pause / Step / Freeze		
		Stop / Hold		
		Title Sound / Title		
		Open / Close Eject / Surround		





Original	Replacement	Original	Replacement
On/Off	 Power	Menu Right	 Right
Mute	 Mute / Dimmer	Menu Down	 Down
Txt Stop	 Stop / Hold	Back	 Back / Return
Tone+	 >> / Tune+	Volume+	 Vol+
Lang	 Sound / Title	Chan.Up	 CH+ / Page+
Menu audio	 Audio / Lang I/II	Volume-	 Vol-
Subt.List	 Subtitle / EQ	Display	 Display / Media
Txt Expand	 Zoom / Size	Chan.Down	 CH- / Page-
Sleep Timer	 Sleep / Timer	1	 1
Return TV	 TV/Radio /	2	 2
Menu video	 D.Menu / Top	3	 3
Text	 Text / Goto	4	 4
Menu	 Menu / Home	5	 5
Menu Up	 Up	6	 6
Info	 Info / Angle	7	 7
Menu Left	 Left	8	 8
OK Enter	 OK	9	 9

Original	Replacement	Original	Replacement
Menu Right	 Right	Menu Down	 Down
Menu Down	 Down	Back	 Back / Return
Back	 Back / Return	Volume+	 Vol+
Volume+	 Vol+	Chan.Up	 CH+ / Page+
Chan.Up	 CH+ / Page+	Volume-	 Vol-
Volume-	 Vol-	Display	 Display / Media
Display	 Display / Media	Chan.Down	 CH- / Page-
Chan.Down	 CH- / Page-	1	 1
1	 1	2	 2
2	 2	3	 3
3	 3	4	 4
4	 4	5	 5
5	 5	6	 6
6	 6	7	 7
7	 7	8	 8
8	 8	9	 9
9	 9		



