


































Original	Replacement
Power Receiver	Power
Input Select	AV
DVD/LD	Shift + 1
TV/SAT	Shift + 5
DVR/VCR	Shift + 2
CD	Shift + 4
CD-R/Tape	Shift + 6
TUNER	Shift + 3
Standard	Red
Advanced	Green
Stereo	Yellow
Midnight /	Blue
CH. Select	Smart
Level-	Ch -
Level+	Ch +
Test Tone	Media
Effect -	Shift + Down

Original	Replacement
Effect +	Shift + Up
FL Dimmer	D. Menu
Mute	Mute
Master Volume-	Vol -
Master	Vol +
Up/Tune+	Up
Menu	Menu
Left/ST-	Left
Enter	Ok
Right/ST+	Right
Setup	Options
Down/Tune-	Down
Sleep	Sleep
Guide	Guide
<<	<<
Play	Play
>>/A	>>















































Original		Replacement		Original		Replacement	
	Power Source		Power		1		1
	DVD		Smart		2		2
	Top Menu		Ch +		3		3
	Up		Up		Enter		Pre Ch
	Menu		Ch -		4		4
	Left		Left		5		5
	Enter		Ok		6		6
	Right		Right		+10		Guide
	Audio		Dual		7		7
	Down		Down		8		8
	<<		<<		9		9
	Play		Play		0		0
	>>		>>				
	I<<		I<<				
	Pause		Pause				
	Stop		Stop				
	>>I		>>I				





Original	Replacement	Original	Replacement
 Power Source	 Power	 5	 5
 Tuner	 Smart	 6	 6
 Tune+	 Up	 7	 7
 Menu	 Menu	 8	 8
 ST-	 Left	 9	 9
 Enter	 Ok	 0	 0
 ST+	 Right		
 Tune-	 Down		
 Band	 Stop		
 Display	 Back		
 Class	 Pause		
 MPX	 I<<		
 D.Access	 >>I		
 1	 1		
 2	 2		
 3	 3		
 4	 4		

