Original	Replacement	Original	Replacement
Power	Power	Stop	Stop
Open/Close	Eject	Menu	Menu
CD/FM	Yellow	RDS/Display	Info
Dock	Blue	Repeat/Shuffle	Text
Audio In/USB	Red	Prog	Shift + Sleep
Preset/Album	Up	Sound	Dual
Preset/Album	Down	Clock	AV
>>I	>>I	Sleep/Timer	Sleep
>>I	Right		
I<<	I<<		
I<<	Left		
OK	Ok		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute		
Play	Play		
Pause	Pause		

Original	Replacement	Original	Replacement
Power	Power	Stop	Stop
Open/Close	Eject	Menu	Menu
CD/FM	Yellow	RDS/Display	Info
Dock	Blue	Repeat/Shuffle	Text
Audio In/USB	Red	Prog	Shift + Sleep
Preset/Album	Up	Sound	Dual
Preset/Album	Down	Clock	AV
>>I	>>I	Sleep/Timer	Sleep
>>I	Right		
I<<	I<<		
I<<	Left		
OK	Ok		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute		
Play	Play		
Pause	Pause		

Original	Replacement	Original	Replacement
Power	Power	Stop	Stop
Open/Close	Eject	Menu	Menu
CD/FM	Yellow	RDS/Display	Info
Audio In/USB	Red	Repeat/Shuffle	Text
Dock	Blue	Prog	Shift + Sleep
Preset/Album	Up	Sound	Dual
Preset/Album	Down	Clock	AV
>>I	>>I	Sleep/Timer	Sleep
>>I	Right		
I<<	I<<		
I<<	Left		
OK	Ok		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute		
Play	Play		
Pause	Pause		