Original		Replacement	
DVD/VHS	DVD/VHS Power		Power
TV	TV Power	SHIFT +	Shift + Power
CH	TV CH +	SHIFT + CH PAGE	Shift + CH+ /
VOLUME	TV Volume +	VOL	Vol +
DRIVE SELECT	Drive Select	LIST SMART	Smart / List
AV	TV AV	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH	TV CH -	SHIFT + CH PAGE	Shift + CH- /
VOLUME	TV Volume -	VOL	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
CH	CH + / Tracking/V-Lock	CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	CH - / Tracking/V-Lock	CH PAGE	CH- / Page-
7	7	AUX - HDD 7	7

Original		Replacement	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
ShowView	ShowView	TITLE SOUND	Sound / Title
* RESET	* / Reset	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
DELETE	Delete	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SKIP/I	I<<	PRESET-	I<< / Preset-
INDEX	>>I	PRESET+	>>I / Preset+
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
TIME SLIP/◄◄ JET	Time Slip / <<J Rew	SHIFT + TUNE-	Shift + << /
MANUAL SKIP	Manual Skip	TIMER SLEEP	Sleep / Timer
PROG/CHECK	Prog Check	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement		Original		Replacement
	Direct Navigator	TOP MENU D.MENU	D. Menu / Top			
	Left / ◁II		Left			
ENTER	Enter	OK	OK			
	Up		Up			
	Right / II▷		Right			
	Functions	HOME MENU	Menu / Home			
SUB MENU S	Sub Menu	ANGLE INFO	Info / Angle			
	Down		Down			
RETURN	Return	RETURN BACK	Back / Return			
AUDIO A	Audio	LANG I/II AUDIO	Audio / Lang I/II			
DISPLAY B	Display	MEDIA DISPLAY	Display / Media			
CREATE CHAPTER C	Create Chapter	PROGRAM TV/ RADIO	TV/Radio /			
STATUS	Status	FORMAT PICTURE	Picture / Format			
REC	Rec	REC MODE	Rec / Rec Mode			
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec / Rec Mode			
EXT LINK	Ext Link	GOTO TEXT	Text / Goto			
DIRECT TV REC	Direct TV Rec	SIZE ZOOM	Zoom / Size			