| Original | | Replacement | |
|---|---|---|---|
| ON/OFF | On/Off | ON/OFF | Power |
| MUTE | Mute | MUTE | Mute |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| TV GUIDE | Tv Guide | GUIDE | Guide |
| | Recall | FAV PRE-CH | Pre Ch |
| VOL + | Vol + | VOL + | Vol + |
| VOL − | Vol - | VOL − | Vol - |
| PICTURE | Picture | PICTURE FORMAT | Format |

| Original | | Replacement | |
|---|---|---|---|
| SOUND | Sound | SOUND DUAL | Dual |
| SOURCE | Source | TIMER AV | AV |
| CH+ | CH+ | CH + | Ch + |
| CH− | CH- | CH − | Ch - |
| MENU | Menu | TOP MENU MENU | Menu |
| EXIT | Exit | CLEAR EXIT | Exit |
| FAV | FAV | SHIFT + FAV PRE-CH | Shift + Pre Ch |
| BACK | Back | RETURN BACK | Back |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| OK | OK | OK | Ok |
| INFO | Info | DISPLAY INFO | Info |
| TEXT | Text | REPEAT TEXT | Text |
| SUBTITLE | Subtitle | AD SUBT | Subt |
| TV | TV | SEARCH TV/R | TV/R |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| YouTube | | APP MEDIA | Media | | |
| NETFLIX | Netflix | HOME SMART | Smart | | |
| NET+ | Net+ | SHIFT + APP MEDIA | Shift + Media | | |
| DVD MENU | Rec/DVD Menu | REC MODE | Rec | | |
| ⏮ | I<< | ⏮ | I<< | | |
| ⏭ | >>I | ⏭ | >>I | | |
| ■ | Stop | ■ | Stop | | |
| ◀◀ | << | ◀◀ | << | | |
| ▶▶ | >> | ▶▶ | >> | | |
| ▶II | Play | PLAY MODE ▶ | Play | | |
| ▶II | Pause | II | Pause | | |
| DVD SETUP REC LIST | Rec List/DVD | DISC NAV LIST | List | | |
| GOTO | Red/Goto | A | Red | | |
| A-B | Green/A-B | B | Green | | |
| ANGLE | Yellow/Angle | C | Yellow | | |
| REPEAT | Blue/Repeat | D | Blue | | |
| | | | | | |