Original		Replacement	
	Open/Close		Eject / Surround
	Power		Power
ZOOM RED	Red/Zoom	NETFLIX SEARCH	Red / Netflix / Search
PROGRAM GREEN	Green/Program	APP REPEAT	Green / APP / Repeat
SHUFFLE YELLOW	Yellow/Shuffle	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT BLUE	Blue/Repeat	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
SEARCH	Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
REPEAT A/B	Repeat A/B	SHIFT + APP REPEAT	Shift + Green / APP /
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Angle	ANGLE INFO	Info / Angle
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
PIP	PIP	FORMAT PICTURE	Picture / Format
2ND AUDIO	2nd Audio	DIMMER MUTE	Mute / Dimmer
MIRACAST	Miracast	SHIFT + MEDIA DISPLAY	Shift + Display / Media
HOME	Home	HOME MENU	Menu / Home
YouTube	YouTube	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
vudu	Vidi	GOTO TEXT	Text / Goto
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
POP-UP/MENU	Pop-Up Menu	LIST SMART	Smart / List
RETURN	Return	SHIFT + RETURN BACK	Shift + Back / Return
ON SCREEN	On Screen	MEDIA DISPLAY	Display / Media
	Up		Up
	Down		Down

Original	Replacement	Original	Replacement
Left	Left		
Right	Right		
Enter	OK		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Play	Play / Slow		
<<I	CH- / Page-		
I >>	CH+ / Page+		
<<	<< / Tune-		
>>	>> / Tune+		
Setup	Setup / OPT /		
Status	Back / Return		
I <<	I << / Preset-		
>>I	>>I / Preset+		