Mandis shop

Philips RD5501-00

Original		Replacement	
TRA	< Track	PRESET-	I<< / Preset-
ACK	Track >	PRESET+	>>I / Preset+
PLAY REPLAY	Play	SLOW	Play / Slow
IND	< Index	CH PAGE	CH- / Page-
DEX	Index >	CH PAGE	CH+ / Page+
STOP	Stop	HOLD	Stop / Hold
SEAR	< Search	TUNE-	<< / Tune-
ARCH	Search >	TUNE+	>> / Tune+
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original		Replacement	
9	9	BLUETOOTH 9	9
CLEAR	C	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CLEAR	C	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
STORE	S	PC FAV MARKER	Fav / Marker / PC
REV	Review	ANGLE INFO	Info / Angle
A→B	A-->B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
SCAN	Scan	MEDIA DISPLAY	Display / Media