| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Stop | Stop |
| Open/Close | Eject | Menu | Menu |
| CD/FM | Yellow | RDS/Display | Info |
| Dock | Blue | Repeat/Shuffle | Text |
| Audio In/USB | Red | Prog | Shift + Sleep |
| Preset/Album | Up | Sound | Dual |
| Preset/Album | Down | Clock | AV |
| >>I | >>I | Sleep/Timer | Sleep |
| >>I | Right | | |
| I<< | I<< | | |
| I<< | Left | | |
| OK | Ok | | |
| Vol + | Vol + | | |
| Vol - | Vol - | | |
| Mute | Mute | | |
| Play | Play | | |
| Pause | Pause | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Stop | Stop |
| Open/Close | Eject | Menu | Menu |
| CD/FM | Yellow | RDS/Display | Info |
| Dock | Blue | Repeat/Shuffle | Text |
| Audio In/USB | Red | Prog | Shift + Sleep |
| Preset/Album | Up | Sound | Dual |
| Preset/Album | Down | Clock | AV |
| >>I | >>I | Sleep/Timer | Sleep |
| >>I | Right | | |
| I<< | I<< | | |
| I<< | Left | | |
| OK | Ok | | |
| Vol + | Vol + | | |
| Vol - | Vol - | | |
| Mute | Mute | | |
| Play | Play | | |
| Pause | Pause | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Stop | Stop |
| Open/Close | Eject | Menu | Menu |
| CD/FM | Yellow | RDS/Display | Info |
| Audio In/USB | Red | Repeat/Shuffle | Text |
| Dock | Blue | Prog | Shift + Sleep |
| Preset/Album | Up | Sound | Dual |
| Preset/Album | Down | Clock | AV |
| >>I | >>I | Sleep/Timer | Sleep |
| >>I | Right | | |
| I<< | I<< | | |
| I<< | Left | | |
| OK | Ok | | |
| Vol + | Vol + | | |
| Vol - | Vol - | | |
| Mute | Mute | | |
| Play | Play | | |
| Pause | Pause | | |