Mandis shop

Philips RC19532018-01

Original		Replacement	
	Power		Power
	Tuner	A	Red
	AUX	B	Green
	Tape	C	Yellow
	USB	D	Blue
	CD1	1	1
	CD2	2	2
	CD3	3	3
	USB Record	REC MODE	Rec
	USB Delete	CLEAR EXIT	Exit
	Vol -	VOL −	Vol -
	Vol +	+ VOL	Vol +
	I</Title	I<<	I<<
	>I/Title	>>I	>>I
	Stop		Stop
	Play/Pause	PLAY MODE	Play
	Play/Pause		Pause

Original		Replacement	
	<</Album	<<	<<
	>>/Album	>>	>>
DSC	DSC		Up
IS	IS		Left
RDS/NEWS	RDS/News		Right
DIM	DIM		Down
PROG	Prog	SHIFT + PROG SLEEP	Shift + Sleep
REPEAT	Repeat	REPEAT TEXT	Text
SHUFFLE	Shuffle	SEARCH TV/R	TV/R
DISPLAY	Display	DISPLAY INFO	Info
SLEEP	Sleep	PROG SLEEP	Sleep
CLOCK TIMER	Clock Timer	SHIFT + TIMER AV	Shift + AV
TIMER ON/OFF	Timer On/Off	TIMER AV	AV
MUTE	Mute	MUTE	Mute
DBB	DBB	APP MEDIA	Media
MAX	Max	HOME SMART	Smart