Original		Replacement		Original		Replacement	
POWER	Power		Power	EXIT	Exit	CLEAR EXIT	Exit
MUTE	Mute	MUTE	Mute		Up		Up
1	1	1	1		Down		Down
2	2	2	2		Right		Right
3	3	3	3		Left		Left
4	4	4	4	OK	OK	OK	Ok
5	5	5	5	+ VOL	Vol +	+ VOL	Vol +
6	6	6	6	VOL –	Vol -	VOL –	Vol -
7	7	7	7	SOUND	Sound	SOUND DUAL	Dual
8	8	8	8	PIC	P/C	FAV PRE-CH	Pre Ch
9	9	9	9	+ CH	CH+	+ CH	Ch +
0	0	0	0	CH –	CH-	CH –	Ch -
TV AUDIO	Eject/Tv Audi c	ZOOM	Eject	SLEEP	Sleep	PROG SLEEP	Sleep
RECALL/GOTO	Recall/Goto	RETURN BACK	Back	ASPECT	Aspect	ECO 3D	3D
TV MENU	Tv Menu	TOP MENU MENU	Menu	DVD SETUP	Rec/DVD Setup	REC MODE	Rec
SOURCE	Source	TIMER AV	AV	TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
DVD MENU	DVD Menu	E-MANUAL D.MENU	D. Menu	TEXT	Text	REPEAT TEXT	Text

Original		Replacement	
EPG	EPG/Play-Pause	-/-- GUIDE	Guide
FAV	Stop/FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
INFO	Info	DISPLAY INFO	Info
DVD/USB	Red/DVD/USB	A	Red
TITLE	Green/Title	B	Green
PBC	Yellow/PBC	C	Yellow
ANGLE	Blue/Angle	D	Blue
<<	<<	<<	<<
>>	>>	>>	>>
I<<	I<<	I<<	I<<
>>I	>>I	>>I	>>I
RETURN	Play/Return (Red	PLAY MODE ▶	Play
DISPLAY	Pause/Display	II	Pause
DVD AUDIO	Stop/DVD Audio (Red)	■	Stop
SUBTITLE	Subtitle	AD SUBT	Subt
REVEAL	Reveal	SETTINGS OPT	Options
HOLD	Hold	HOME SMART	Smart

Original		Replacement	
LIST	List	DISC NAV LIST	List
INDEX	Index	SHIFT + DISPLAY INFO	Shift + Info
SUBPAGE	Subpage	SHIFT + AD SUBT	Shift + Subt
SIZE	Size	PICTURE FORMAT	Format
MIX	MIX	SHIFT + PROG SLEEP	Shift + Sleep
FREEZE	Freeze	APP MEDIA	Media