Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
FAV	FAV	FAV PRE-CH	Pre Ch
SUBTITLE	Subtitle	AD SUBT	Subt
INFO	Info	DISPLAY INFO	Info
TTX	TTX	REPEAT TEXT	Text
RECALL	Recall	RETURN BACK	Back
LIST	List	DISC NAV LIST	List
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
EPG	EPG	- / -- GUIDE	Guide
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
TIMER	Timer	TIMER AV	AV
Pg Dn	Pg Dn	SHIFT + CH −	Shift + Ch -
Pg Up	Pg Up	SHIFT + + CH	Shift + Ch +
<<	<<	<<	<<
>>	>>	>>	>>
I<<	I<<	I<<	I<<

Original		Replacement	
	>>I		>>I
CH +	CH +	CH +	Ch +
CH -	CH -	CH -	Ch -
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
AUDIO	Audio	SOUND DUAL	Dual
PAL/NTSC	PAL / NTSC	ECO 3D	3D
SLEEP	Sleep	PROG SLEEP	Sleep
TV/RADIO	TV / Radio	SEARCH TV/R	TV/R
	Red	A	Red
ASPECT	Aspect	PICTURE FORMAT	Format
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue

Original	Replacement

Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
FAV	FAV	FAV PRE-CH	Pre Ch
SUBTITLE	Subtitle	AD SUBT	Subt
INFO	Info	DISPLAY INFO	Info
TTX	TTX	REPEAT TEXT	Text
RECALL	Recall	RETURN BACK	Back
LIST	List	DISC NAV LIST	List
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
EPG	EPG	-/-- GUIDE	Guide
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
TIMER	Timer	TIMER AV	AV
Pg Dn	Pg Dn	SHIFT + CH −	Shift + Ch -
Pg Up	Pg Up	SHIFT + + CH	Shift + Ch +
<<	<<	<<	<<
>>	>>	>>	>>
I<<	I<<	I<<	I<<

Original		Replacement	
	>>I		>>I
CH +	CH +	CH +	Ch +
CH -	CH -	CH -	Ch -
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
AUDIO	Audio	SOUND DUAL	Dual
PAL/NTSC	PAL / NTSC	ECO 3D	3D
SLEEP	Sleep	PROG SLEEP	Sleep
TV/RADIO	TV / Radio	SEARCH TV/R	TV/R
	Red	A	Red
ASPECT	Aspect	PICTURE FORMAT	Format
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue

Original	Replacement

Original	Replacement	
Power		Power
Mute	MUTE	Mute
FAV	FAV PRE-CH	Pre Ch
Subtitle	AD SUBT	Subt
Info	DISPLAY INFO	Info
TTX	REPEAT TEXT	Text
List	DISC NAV LIST	List
Recall	RETURN BACK	Back
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9

Original	Replacement	
0	0	0
Menu	TOP MENU MENU	Menu
Exit	CLEAR EXIT	Exit
EPG	-/-- GUIDE	Guide
Swap	APP MEDIA	Media
Up		Up
Down		Down
Right		Right
Left		Left
OK	OK	Ok
Vol+	+ VOL	Vol +
Vol-	VOL –	Vol -
Pg Up	SHIFT +	Shift + Up
PG Dn	SHIFT +	Shift + Down
CH+	+ CH	Ch +
CH-	CH –	Ch -
>>		>>

Original	Replacement		Original	Replacement
<<		<<		
>>I		>>I		
I<<		I<<		
Play	PLAY MODE	Play		
Pause/Timeshift		Pause		
Stop		Stop		
Rec	REC MODE	Rec		
Audio	SOUND DUAL	Dual		
M/P	HOME SMART	Smart		
Tv/Radio	SEARCH TV/R	TV/R		
A-B	SETTINGS OPT	Options		
Red/Zoom	A	Red		
Green/Aspect	B	Green		
Yellow/V-Formet	C	Yellow		
Blue/Timer	D	Blue		