Original		Replacement	
Power	Power	Power	Power
TV	TV	SEARCH TV/R	TV/R
Mute	Mute	MUTE	Mute
1	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
0 SPACE	0	0	0
SOURCE	Source	TIMER AV	AV
INFO	Info	DISPLAY INFO	Info
+ P	P+	+ CH	Ch +
P –	P-	CH –	Ch -

Original		Replacement	
+ V	Vol+	+ VOL	Vol +
V –	Vol-	VOL –	Vol -
OPTION	Option	SETTINGS OPT	Options
Smart TV	Smart Tv	HOME SMART	Smart
GUIDE	Guide	- / -- GUIDE	Guide
MENU	Menu	TOP MENU MENU	Menu
	Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
LIST	List	DISC NAV LIST	List
	@/Home	SHIFT + HOME SMART	Shift + Smart
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
PRE-CH	Pre-CH	FAV PRE-CH	Pre Ch
OO/LANG	OO/Lang	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
TEXT	Text	REPEAT TEXT	Text
	Red	A	Red
ECO	Eco	ECO 3D	3D

Original		Replacement	
ZOOM-	Zoom-	ZOOM	Eject
ZOOM+	Zoom+	PICTURE FORMAT	Format
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Up		Up
	Down		Down
	Right		Right
OK	OK	OK	Ok
	Left		Left
	Stop		Stop
	Rec	REC MODE	Rec
	Play	PLAY MODE	Play
	>I		>>I
	I<		I<<
	>>		>>
	<<		<<

Original		Replacement	
	Pause		Pause
SLEEP	Sleep	PROG SLEEP	Sleep
NETFLIX	Netflix	APP MEDIA	Media