Mandis shop

RB-DA70

Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TUNING+	>>I/Tuning+	>>I	>>I
TUNING–	I<</Tuning-	I<<	I<<
▶/II	Play	PLAY MODE ▶	Play
▶/II	Pause	II	Pause
■	Stop	■	Stop
MEMORY	Memory	REC MODE	Rec
REPEAT/ FM MODE	Repeat /FM Mode	REPEAT TEXT	Text

Original		Replacement	
PRESET	Preset	SETTINGS OPT	Options
BAND	Band	SEARCH TV/R	TV/R
– +	Vol+	+ VOL	Vol +
– +	Vol-	VOL –	Vol -

https://mandisshop.ie/en/Sanyo/1063840-91427-replacement-remote-control-for-Sanyo-RB-DA70.html