Original		Replacement	
TV	Power		Power
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
RETURN	Return	RETURN BACK	Back / Return
TV VOL +	Tv Vol+	+ VOL	Vol+
CH	CH+	+ CH PAGE	CH+ / Page+
	Tv Vol-	VOL −	Vol-
	CH-	CH PAGE −	CH- / Page-
TV MUTE	Mute Tv	DIMMER MUTE	Mute / Dimmer
TV INPUT	Input Tv	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3

Original		Replacement	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
ENT	ENT	SHIFT + OK	Shift + OK

Original		Replacement	
	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
MEMORY	Play/Memory	SLOW	Play / Slow
PRESET	Pause/Preset	STEP-FREEZE	Pause / Step / Freeze
PRESET	Stop/Preset Up	HOLD	Stop / Hold
TUNING	<<</Tuning Up	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
TUNING	I<<</Tuning	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
MUSIC	Music	TITLE SOUND	Sound / Title
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
MOVIE	Movie	FORMAT PICTURE	Picture / Format
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TV	TV	PROGRAM TV/ RADIO	TV/Radio /
SUR. DECODE	Sur Decode	TOP MENU D.MENU	D.Menu / Top
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement	
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOLUME	Vol+	VOL	Vol+
iPod	iPod	LIST SMART	Smart / List
	Vol-	VOL	Vol-
ENTER TAINMENT	Entertainment	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6

Original		Replacement	
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
HDMI1	HDMI 1	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
HDMI2	HDMI 2	PC FAV MARKER	Fav / Marker / PC
OFF	Off	SHIFT +	Shift + Power
	Pause/Preset	SHIFT + STEP - FREEZE II	Shift + Pause / Step /
	Stop/Preset Up	SHIFT + HOLD ■	Shift + Stop /
	<<</Tuning Up	SHIFT + TUNE- ◀◀	Shift + << /
	I<<</Tuning	SHIFT + PRESET- ⏮	Shift + I<< / Preset-
UNIVOLUME	Univolume	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
FM	FM	SHIFT + PROGRAM TV/ RADIO	Shift + TV/Radio / Program
INTELLIBEAM	Intellibeam	SHIFT + TOP MENU D.MENU	Shift + D.Menu / Top Menu
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
ENT	ENT	SHIFT + OK	Shift + OK
AUX1	AUX1	SHIFT + TV 1	Shift + 1

Original		Replacement	
AUX2	AUX2	SHIFT + DVD 2	Shift + 2
HDMI3	HDMI 3	SHIFT + CD - STB 3	Shift + 3
HDMI4	HDMI 4	SHIFT + VIDEO 4	Shift + 4

Original		Replacement	
	Power		Power
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
MENU	Menu	HOME MENU	Menu / Home
RETURN	Return	RETURN BACK	Back / Return
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8

Original		Replacement	
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
ENT	ENT	PC FAV MARKER	Fav / Marker / PC
TUNING	<<	TUNE+	>> / Tune+
PRESET	Stop	HOLD	Stop / Hold
	>>	PRESET-	I<< / Preset-
TUNING	I<<	TUNE-	<< / Tune-
PRESET	Pause	STEP - FREEZE	Pause / Step / Freeze
	>>I	PRESET+	>>I / Preset+
MEMORY	Play	SLOW	Play / Slow