Mandis shop

Grundig RP100

Original		Replacement	
STANDBY	Standby		Power
CASS.	Cass	SOUND DUAL	Dual
TIMER	Timer	SHIFT + TIMER AV	Shift + AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+	+	+ CH	Ch +
-	-	CH −	Ch -
SEL./VPS	SEL/VPS	-/-- GUIDE	Guide
CLEAR	Clear	CLEAR EXIT	Exit

Original		Replacement	
RECORD/OTR	Record/OTR	REC MODE	Rec
STILL	Still	HOME SMART	Smart
<<	<<	<<	<<
>>	>>	>>	>>
PLAY	Play	PLAY MODE ▶	Play
PREVIOUS	Previous	K<	I <<
NEXT	Next	>>I	>>I
PAUSE/STOP	Pause	II	Pause
PAUSE/STOP	Stop	■	Stop
MONITOR	Monitor	TIMER AV	AV
TUNER	Tuner	SEARCH TV/R	TV/R
TRACKING	Tracking	SETTINGS OPT	Options
SP/LP	SP/LP	APP MEDIA	Media