Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
MENU	Menu	HOME MENU	Menu / Home
0	0	HDMI - SAT 0	0
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH+	Up		Up
CH+	CH+	+ CH PAGE	CH+ / Page+
V-	Vol-	VOL −	Vol-

Original		Replacement	
V-	Left		Left
OK	OK	OK	OK
V+	Vol+	+ VOL	Vol+
V+	Right		Right
CH-	CH-	CH PAGE −	CH- / Page-
CH-	Down		Down
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EPG	Red	NETFLIX SEARCH	Red / Netflix / Search
TTX	TTX	GOTO TEXT	Text / Goto
TTX	Blue	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
AUDIO	Green	APP REPEAT	Green / APP / Repeat
SUBTITLE	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
i	i	ANGLE INFO	Info / Angle
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
TV/RADIO	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio / Program

Original	Replacement	Original	Replacement
VIDEO Video	SHIFT + VIDEO 4 Shift + 4		
SCAN Scan	RDS AV INPUT AV / Input / RDS		
RECORD Record	REC MODE Rec / Rec Mode		
DEVICE Device	LIST SMART Smart / List		
FILE File	MEDIA DISPLAY Display / Media		
ZOOM Zoom	SIZE ZOOM Zoom / Size		
PREV Prev	PRESET- I<< / Preset-		
NEXT Next	PRESET+ >>I / Preset+		
ROLL Roll	TITLE SOUND Sound / Title		
▶/II Play	SLOW ▶ Play / Slow		
▶/II Pause	STEP-FREEZE II Pause / Step / Freeze		
<<	TUNE- << / Tune-		
>>	TUNE+ >> / Tune+		