Original		Replacement		Original		Replacement	
STANDBY	Standby		Power	AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
EJECT	Eject	SURROUND	Eject / Surround	OSD	OSD	MEDIA DISPLAY	Display / Media
1	1	TV 1	1	ANGLE	Angle	SHIFT + ANGLE INFO	Shift + Info / Angle
2	2	DVD 2	2	ZOOM	Zoom	SIZE ZOOM	Zoom / Size
3	3	CD - STB 3	3	RETURN	Return	RETURN BACK	Back / Return
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ	TITLE	Title	TITLE SOUND	Sound / Title
4	4	VIDEO 4	4		Up		Up
5	5	TAPE 5	5	MENU	Menu	HOME MENU	Menu / Home
6	6	TUNER 6	6		Left		Left
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	SELECT	Select	OK	OK
7	7	AUX - HDD 7	7		Right		Right
8	8	USB 8	8	SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
9	9	BLUETOOTH 9	9		Down		Down
GOTO	Goto	GOTO TEXT	Text / Goto	PSM	PSM	PROGRAM TV/ RADIO	TV/Radio /
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--	PLAY	Play	SLOW	Play / Slow
0	0	HDMI - SAT 0	0	STOP	Stop	HOLD	Stop / Hold
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear	PAUSE/STEP	Pause/Step	STEP - FREEZE	Pause / Step / Freeze

Original		Replacement		Original		Replacement
REV	<<	TUNE-	<< / Tune-			
FWD	>>	TUNE+	>> / Tune+			
I<<	I<<	PRESET-	I<< / Preset-			
>>I	>>I	PRESET+	>>I / Preset+			
SLOW	Slow	SHIFT + SLOW	Shift + Play /			
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat			
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat			
P/N	P/N	TOP MENU D.MENU	D.Menu / Top			
♭ K	Key L	CH PAGE +	CH+ / Page+			
#	Key #	CH PAGE -	CH- / Page-			
VOL -	Vol -	VOL -	Vol -			
VOL +	Vol +	VOL +	Vol +			
INFO	Info	ANGLE INFO	Info / Angle			
KEYBOARD	Keyboard	LIST SMART	Smart / List			
IS	IS	PC FAV MARKER	Fav / Marker / PC			
PS	PS	FORMAT PICTURE	Picture / Format			