Original	Replacement	Original	Replacement
Power	Power	0	0
Up	Up	Exit/-/--	Exit
Down	Down	PP	Pre Ch
Right	Right	Swap/P<P	Smart
Left	Left	CH+	Ch +
OK/Select	Ok	CH-	Ch -
M	Menu	Vol +	Vol +
[i]/Info	Info	Vol -	Vol -
1	1	Mute	Mute
2	2	I-II	Dual
3	3	Tv/DTV	TV/R
4	4	AV/Source	AV
5	5	Red/↑	Red
6	6	Green/↓	Green
7	7	Yellow	Yellow
8	8	Blue	Blue
9	9	[≡]	Text

Original	Replacement	Original	Replacement
[≡+] / [X]	PICTURE FORMAT — Format		
[≡x] / [■■]	AD SUBT — Subt		
[≡o]	SETTINGS OPT — Options		
[≡♦] / [+] / Wide	ECO 3D — 3D		
[. ≡] / [■]	RETURN BACK — Back		
[≡?]	APP MEDIA — Media		
Guide/ [≡i]	-/-- GUIDE — Guide		