Original	Replacement	Original	Replacement
Power	Power	Exit / TV-G	Exit
1	1	?	Smart
2	2	@	Media
3	3	Menu/i	Menu
4	4	Back	Back
5	5	Tools	Options
6	6	Guide	Guide
7	7	OK	Ok
8	8	Up	Up
9	9	Down	Down
0	0	Right	Right
FAV/ ZAPP	Pre Ch	Left	Left
TXT	Text	Vol +	Vol +
Red	Red	Vol -	Vol -
Green	Green	PR+	Ch +
Yellow	Yellow	PR-	Ch -
Blue	Blue	AV	AV

Original		Replacement		Original	Replacement
	Mute	MUTE	Mute		
	I <		I <<		
	>I		>>I		
	<<		<<		
	>>		>>		
	Rec	REC MODE	Rec		
	Play	PLAY MODE	Play		
	Pause		Pause		
	Stop		Stop		
3D	3D/Search	PICTURE FORMAT	Format		
	../Audio	SOUND DUAL	Dual		
	[...]..	AD SUBT	Subt		
PIP/ECO	PIP/ECO	ECO 3D	3D		
CEC My Media	My Media/CEC	SEARCH TV/R	TV/R		