Original	Replacement
Power	Power
Mute	MUTE
TV	HOME SMART
Tv/Rad	SEARCH TV/R
Audio	SOUND DUAL
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Text	REPEAT TEXT
Sub	AD SUBT

Original	Replacement
EPG	GUIDE
Menu	TOP MENU MENU
Exit	CLEAR EXIT
ALT	APP MEDIA
Up	Up
Down	Down
Right	Right
Left	Left
OK	OK
CH+	CH +
CH-	CH -
Vol +	VOL +
Vol -	VOL -
Freeze	Pause
Browse	SETTINGS OPT
Page+	>>
Page-	<<

Original		Replacement		Original	Replacement
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
	i	DISPLAY INFO	Info		