Original		Replacement		Original		Replacement	
	Power		Power		P+		CH+ / Page+
	1		1		P+		Up
	2		2		-		Left
	3		3		-		Vol -
	PIP		Smart / List		OK		OK
	4		4		+		Right
	5		5		+		Vol +
	6		6		TXT		Text / Goto
	[<>]		Picture / Format		P-		CH- / Page-
	7		7		P-		Down
	8		8		AV		AV / Input / RDS
	9		9		Scan/[ ]		Setup / OPT /
	-/--		Guide / EPG / -/--		PAP/Pause		Display / Media
	0		0		Size/Stop		Zoom / Size
	Mute		Mute / Dimmer		Pos/Play		D.Menu / Top
	i		Info / Angle		Red/I<		Red / Netflix / Search
	Z		Menu / Home		Green/>I		Green / APP / Repeat

Original	Replacement	Original	Replacement
Yellow/ Pause/ <	Yellow / YouTube / Repeat		
Blue/ >>	Blue / Prime Video / Random		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	PIP		Smart / List
	4		4
	5		5
	6		6
	[<>]		Picture / Format
	7		7
	8		8
	9		9
	-/--		Guide / EPG / -/--
	0		0
	i		Info / Angle
	Z		Menu / Home
	P+		CH+ / Page+

Original		Replacement	
	P+		Up
	-		Left
	-		Vol -
	OK		OK
	+		Right
	+		Vol +
	TXT		Text / Goto
	P-		CH- / Page-
	P-		Down
	AV		AV / Input / RDS
	Scan/[']		Setup / OPT /
	PAP/Pause		Pause / Step / Freeze
	Size/Stop		Stop / Hold
	Pos/Play		Play / Slow
	Red/I<		I<< / Preset-
	Green/>I		>>I / Preset+
	Yellow/Pause/<		<< / Tune-

Original	Replacement	Original	Replacement
Bl ue/ >>	>> / Tune+		

Original		Replacement		Original		Replacement	
	Power		Power		P+		CH+ / Page+
	1		1		P+		Up
	2		2		-		Left
	3		3		-		Vol -
	PIP		Smart / List		OK		OK
	4		4		+		Vol +
	5		5		+		Right
	6		6		TXT		Text / Goto
	[<>]		Picture / Format		P-		CH- / Page-
	7		7		P-		Down
	8		8		AV		AV / Input / RDS
	9		9		Scan/[ ]		Setup / OPT /
	-/--		Guide / EPG / -/--		PAP/Pause		Pause / Step / Freeze
	0		0		Size/Stop		Stop / Hold
	Mute		Mute / Dimmer		Pos/Play		Play / Slow
	i		Info / Angle		Red/I<		I<< / Preset-
	Z		Menu / Home		Green/>I		>>I / Preset+

Original	Replacement	Original	Replacement
Yel l ow/ <<	TUNE- << / Tune-		
Bl ue/ >>	TUNE+ >> / Tune+		

Original		Replacement		Original		Replacement	
	Power		Power		P+		Up
	1		1		-		Vol -
	2		2		-		Left
	3		3		OK		OK
	PIP		Smart / List		+		Vol +
	4		4		+		Right
	5		5		TXT		Text / Goto
	6		6		P-		CH- / Page-
	[<>]		Picture / Format		P-		Down
	7		7		AV		AV / Input / RDS
	8		8		Scan/[']		Setup / OPT /
	9		9		PAP/Pause		Pause / Step / Freeze
	-/--		Guide / EPG / -/--		Size/Stop		Stop / Hold
	0		0		Pos/Play		Play / Slow
	i		Info / Angle		Red/I<		I<< / Preset-
	Z		Menu / Home		Green/>I		>>I / Preset+
	P+		CH+ / Page+		Yellow/Pause/<		<< / Tune-

Original	Replacement	Original	Replacement
Bl ue/ >>	>> / Tune+		