Original	Replacement
Power	Power
Home	Smart
Disc Menu	D. Menu
Top Menu	Menu
OK	Ok
Up	Up
Down	Down
Right	Right
Left	Left
Back	Back
≡	Options
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Open/Close	Eject
Play	Play

Original	Replacement
Pause	Pause
Stop	Stop
I<	I<<
>I	>>I
<<	<<
>>	>>
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Subtitle	Subt

Original	Replacement	Original	Replacement
AUDIO Audio	SOUND DUAL Dual		