Original		Replacement	
POWER	Power		Power
DVD	DVD	A	Red
VCR	VCR	B	Green
EJECT OPEN/CLOSE	Eject/Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
AV/INPUT	Av/Input	TIMER AV	AV
FORWARD	>>/Forward		>>

Original		Replacement	
BACKWARD	<<</Backward		<<
SKIP	>>I Skip		>>I
SKI	I<< Skip		I<<
PAUSE/STEP	Pause/Step		Pause
PLAY	Play	PLAY MODE	Play
STOP	Stop		Stop
HOME	Home	HOME SMART	Smart
DISC MENU/LIST	Disc Menu/List	DISC NAV LIST	List
DISPLAY	Display	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
PR/CH TRK	PR/CH TRK +		Up
	PR/CH TRK - Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
AUDIO	O))/Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt

Original	Replacement
ZOOM Zoom	SHIFT + ZOOM Shift + Eject
I.SKIP I. Skip	REPEAT TEXT Text
REC Rec	REC MODE Rec
REC MODE Rec Mode	SHIFT + REC MODE Shift + Rec
DUBBING Dubbing	-/-- GUIDE Guide
TITLE Title	SETTINGS OPT Options
PLAY MODE Play Mode	SHIFT + PLAY MODE Shift + Play
MARKER Marker	C Yellow
- SEARCH - Search	SHIFT + SEARCH TV/R Shift + TV/R
THUMBNAIL Thumbnail	APP MEDIA Media
CHP. ADD CHP. ADD	PICTURE FORMAT Format
TV/VCR Tv/VCR	SEARCH TV/R TV/R
* *	D Blue
SHOWVIEW Show/View	ECO 3D 3D
TV POWER Power Tv	SHIFT + Power Shift + Power
AV/INPUT Av/Input Tv	SHIFT + TIMER AV Shift + AV
PR/CH PR/CH + Tv	+ CH Ch +

Original	Replacement
PR/CH - Tv	CH – Ch -
VOL Vol + Tv	+ VOL Vol +
Vol - Tv	VOL – Vol -