Original		Replacement	
	Power		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
Audio PIP	PI P/ Audi o	ECO 3D	3D
	[<>]	PICTURE FORMAT	For mat
?	?	HOME SMART	Smar t
	Mut e	MUTE	Mut e
Disc Menu Z	Z/ Di sc Menu	TOP MENU MENU	Menu
OSD i	i / OSD	DISPLAY INFO	I nf o

Original		Replacement	
TXT	TXT	REPEAT TEXT	Text
TV-G	TV- G	GUIDE	Gui de
P+	Up		Up
P-	Down		Down
	Ri ght		Ri ght
	Lef t		Lef t
OK	OK	OK	Ok
P+	P+	CH +	Ch +
P-	P-	CH −	Ch -
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Red/ I mage/ I >	A	Red
	Gr een/ Ti mer	B	Gr een
@	Yel l ow/ @	C	Yel l ow
	Bl ue/ Sound	D	Bl ue
	Pl ay	PLAY MODE	Pl ay
@	Pause		Pause

Original		Replacement	
	Stop		Stop
	<<		<<
	>>		>>
	I <		I <<
	>I		>>I

Original	Replacement

Original		Replacement	
	Power		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
OSD i	i/OSD	DISPLAY INFO	Info
TXT	TXT	REPEAT TEXT	Text
TV-G	TV-G	-/-- GUIDE	Guide

Original		Replacement	
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
P+	P+	+ CH	Ch +
P-	P-	CH −	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop

Original		Replacement		Original	Replacement
TXT	<<	<<	<<		
TV-G	>>	>>	>>		
	>I	>>	>>I		
?	I <	<<	I <<		

Original		Replacement	
	Power		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
	Mute	MUTE	Mute
OSD i	i/OSD	DISPLAY INFO	Info
TXT	TXT	REPEAT TEXT	Text

Original		Replacement	
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
TV-G	TV-G	GUIDE	Guide
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
P+	P+	CH +	Ch +
P-	P-	CH −	Ch -
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause

Original		Replacement		Original	Replacement
	Stop		Stop		
TXT	<<		<<		
TV-G	>>		>>		
?	I <		I <<		
	>I		>>I		

Original		Replacement	
	Power		Power
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
Audio PIP	PIP/Audio	ECO 3D	3D
	[<>]	PICTURE FORMAT	Format
?	?	HOME SMART	Smart
OSD i	i/OSD	DISPLAY INFO	Info
TXT	TXT	REPEAT TEXT	Text
TV-G	TV-G	-/-- GUIDE	Guide

Original		Replacement	
Disc Menu Z	Z/Disc Menu	TOP MENU MENU	Menu
P+	P+	+ CH	Ch +
P-	P-	CH −	Ch -
P+	Up		Up
P-	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Red/Image/I>	A	Red
	Green/Timer	B	Green
	Yellow/@	C	Yellow
	Blue/Sound	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop

Original		Replacement		Original	Replacement
TXT	<<	<<	<<		
TV-G	>>	>>	>>		
?	I <	<<	I <<		
	>I	>>	>>I		