Mandis shop

Sony RMSCU37B

Original		Replacement	
I / ⏻	Power	⏻	Power
SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
CLOCK/TIMER SELECT	Clock/Timer	PICTURE FORMAT	Format
CLOCK/TIMER SET	Clock/Timer Set	ECO 3D	3D
TUNER MEMORY	Tuner Memory	RETURN BACK	Back
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode	SHIFT + PLAY MODE ▶	Shift + Play
REPEAT/ FM MODE	Repeat FM	REPEAT TEXT	Text
USB	USB	A	Red
CD	CD	B	Green
TUNER BAND	Band/Tuner	C	Yellow
FUNCTION	Function	D	Blue
⏮ -	I<</-	⏮	I<<
⏭ +	>>I/+	⏭	>>I
◀◀ ←	<</←	◀◀	<<
▶▶ →	>>/→	▶▶	>>
▶	Play	PLAY MODE ▶	Play

Original		Replacement	
⏸	Pause	⏸	Pause
■	Stop	■	Stop
CLEAR	Clear	CLEAR EXIT	Exit
EQ	EQ	SOUND DUAL	Dual
🗀 +	Folder+	+ CH	Ch +
🗀 -	Folder-	CH −	Ch -
+ VOLUME	Vol +	+ VOL	Vol +
VOLUME −	Vol -	VOL −	Vol -
ENTER	Enter	OK	Ok

https://mandis.shop/en/Sony-1528-625-replacement-remote-control-for-Sony-RMSCU37BA16486A.htm