Original	Replacement
Power Receiver	Power
Enter Receiver	Ok
Up Receiver	Up
Down Receiver	Down
Right Receiver	Right
Left Receiver	Left
Return Receiver	Back
Q/Setup Receiver	Smart
Home/Audio	Media
Play Receiver	Play
I<< Receiver	I<<
>>I Receiver	>>I
<< Receiver	<<
>> Receiver	>>
Pause Receiver	Pause
Stop Receiver	Stop
1 Receiver	1

Original	Replacement
2 Receiver	2
3 Receiver	3
4 Receiver	4
5 Receiver	5
6 Receiver	6
7 Receiver	7
8 Receiver	8
9 Receiver	9
0/11 Receiver	0
+10/--/---10/Dimmer/D.Tun Receive	Shift + Guide
CLR/Sleep/12 Receiver	Pre Ch
Movie Tv/Red/Search	Red
Music/Green/Repeat Receiver	Green
Game/Yellow/Random Receiver	Yellow
Stereo/Blue/Mode Receiver	Blue
Vol + Receiver	Vol +
Vol - Receiver	Vol -

Original		Replacement	
CH+ DISC	CH Disc/Album+ Receiver	CH +	Ch +
ALBUM	CH Disc/Album- Receiver	CH −	Ch -
TV	Power Tv	SHIFT +	Shift + Power
TV INPUT	Input Tv	TIMER AV	AV
CH+ DISC	CH+ Tv	SHIFT + CH +	Shift + Ch +
ALBUM	CH- Tv	SHIFT + CH −	Shift + Ch -
	Up Tv	SHIFT + ▲	Shift + Up
ENTER	Enter Tv	SHIFT + OK	Shift + Ok
	Down Tv	SHIFT + ▼	Shift + Down
	Right Tv	SHIFT + ▶	Shift + Right
	Left Tv	SHIFT + ◀	Shift + Left
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return Tv	SHIFT + RETURN BACK	Shift + Back
Q SETUP	Q/Setup Tv	SHIFT + HOME SMART	Shift + Smart
SEARCH MOVIE/TV A	Red Tv	SETTINGS OPT	Options
REPEAT MUSIC B	Green Tv	SOUND DUAL	Dual

Original		Replacement	
RANDOM GAME C	Yellow Tv	AD SUBT	Subt
MODE STEREO D	Blue Tv	SEARCH TV/R	TV/R
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
11 0	0/11 Tv	SHIFT + 0	Shift + 0
--/-- 10 +10 D.TUN DIMMER	+10/--/--10 Tv	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	SHIFT + FAV PRE-CH	Shift + Pre Ch
VOL	Vol + Tv	SHIFT + SOUND DUAL	Shift + Dual
VOL	Vol - Tv	SHIFT + SETTINGS OPT	Shift + Options
AUX	AUX	REPEAT TEXT	Text

Original		Replacement		Original	Replacement
TV/CD	TV/ CD	PICTURE FORMAT	For mat		
CBL/SAT	CBL/ SAT	ECO 3D	3D		
FM	FM	SHIFT +	AD SUBT Shi f t + Subt		
NET	NET	SHIFT +	APP MEDIA Shi f t + Medi a		
PC	PC	SHIFT +	SEARCH TV/R Shi f t + TV/ R		
BD/DVD	BD/ DVD	SHIFT +	REPEAT TEXT Shi f t + Text		
USB	USB	SHIFT +	TIMER AV Shi f t + AV		

Original		Replacement	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Q/Setup	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
PLAY	Play BD/DVD	PLAY MODE	Play
	Pause BD/DVD		Pause

Original		Replacement	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search		Red
REPEAT MUSIC B	Music/Green/Repeat BD/DVD		Green
RANDOM GAME C	Game/Yellow/Random BD/DVD		Yellow
MODE STEREO D	Stereo/Blue/Mode BD/DVD		Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
--/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer BD/DVD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Original		Replacement	
CBL/SAT	CBL/ SAT	REPEAT TEXT	Text
VOL	Vol + Recei ver	+ VOL	Vol +
VOL	Vol - Recei ver	VOL −	Vol -
SOURCE	Power CBL/ SAT	SHIFT +	Shi ft + Power
CH DISC	CH Di sc/ Al bum+ CBL/ SAT	+ CH	Ch +
ALBUM	CH Di sc/ Al bum- CBL/ SAT	CH −	Ch -
MENU PREV CH	Menu/ Pr ev CH CBL/ SAT	SHIFT +	Shi ft + Menu
TOP MENU GUIDE	Top Menu/ Gui de CBL/ SAT	SHIFT +	Shi ft + Opti ons
RETURN	Ret ur n CBL/ SAT	SHIFT +	Shi ft + Back
Q SETUP	Q/ Set up	SHIFT +	Shi ft + Smar t
	Up CBL/ SAT	SHIFT +	Shi ft + Up
ENTER	Ent er CBL/ SAT	SHIFT +	Shi ft + Ok
	Down CBL/ SAT	SHIFT +	Shi ft + Down
	Ri ght CBL/ SAT	SHIFT +	Shi ft + Ri ght
	Lef t CBL/ SAT	SHIFT +	Shi ft + Lef t
	Pause CBL/ SAT	SHIFT +	Shi ft + Pause
	St op CBL/ SAT	SHIFT +	Shi ft + St op

Original		Replacement	
	<< CBL/ SAT	SHIFT + CH −	Shi ft + Ch -
	>> CBL/ SAT	SHIFT + + CH	Shi ft + Ch +
PLAY	Pl ay CBL/ SAT	ECO 3D	3D
SEARCH MOVIE/TV A	Movi e Tv/ Red/ Sear ch	SOUND DUAL	Dual
REPEAT MUSIC B	Musi c/ Gr een/ Repe at CBL/ SAT	AD SUBT	Subt
RANDOM GAME C	Game/ Yel l ow/ Ran dom CBL/ SAT	TIMER AV	AV
MODE STEREO D	St er eo/ Bl ue/ Mode CBL/ SAT	PICTURE FORMAT	For mat
1	1 CBL/ SAT	SHIFT + 1	Shi ft + 1
2	2 CBL/ SAT	SHIFT + 2	Shi ft + 2
3	3 CBL/ SAT	SHIFT + 3	Shi ft + 3
4	4 CBL/ SAT	SHIFT + 4	Shi ft + 4
5	5 CBL/ SAT	SHIFT + 5	Shi ft + 5
6	6 CBL/ SAT	SHIFT + 6	Shi ft + 6
7	7 CBL/ SAT	SHIFT + 7	Shi ft + 7
8	8 CBL/ SAT	SHIFT + 8	Shi ft + 8
9	9 CBL/ SAT	SHIFT + 9	Shi ft + 9
11 0	0/ 11 CBL/ SAT	SHIFT + 0	Shi ft + 0

Original	Replacement	Original	Replacement
BD/DVD	SEARCH TV/R TV/ R		

Original		Replacement	
SOURCE	Power TV/CD		Power
CH DISC +	CH/Disc+ TV/CD	CH +	Ch +
ALBUM −	CH/Disc TV/CD	CH −	Ch -
RETURN	Return TV/CD	RETURN BACK	Back
Q SETUP	Q/Setup TV/CD	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
	Up TV/CD		Up
	Down TV/CD		Down
	Right TV/CD		Right
	Left TV/CD		Left
ENTER	Enter TV/CD	OK	Ok
⏮	I<< TV/CD	⏮	I<<
⏭	>>I TV/CD	⏭	>>I
◀◀	<< TV/CD	◀◀	<<
▶▶	>> TV/CD	▶▶	>>
PLAY	Play TV/CD	PLAY MODE ▶	Play
II	Pause TV/CD	II	Pause

Original		Replacement	
■	Stop TV/CD	■	Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat TV/CD	B	Green
RANDOM GAME C	Game/Yellow/Random TV/CD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode TV/CD	D	Blue
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9
11 0	0/11 TV/CD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer TV/CD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12 TV/CD	FAV PRE-CH	Pre Ch

Original	Replacement	Original	Replacement
Vol + Recei ver	Vol +		
Vol - Recei ver	Vol -		
TV/ CD	TV/ R		

Original		Replacement	
RECEIVER	Power Receiver Zone 2		Power
VOL	Vol + Zone 2	VOL +	Vol +
VOL	Vol - Zone 2	VOL −	Vol -
CH DISC	CH Disc/Album+ Zone 2	CH +	Ch +
ALBUM	CH Disc/Album- Zone 2	CH −	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
	Right Zone 2		Right
	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
Q SETUP	Q/Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Home/Audio Zone	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
PLAY	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Original		Replacement	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Zone 2	B	Green
RANDOM GAME C	Game/Yellow/Random Zone 2	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
11 0	0/11 Zone 2	0	0

Original	Replacement	Original	Replacement
+10/ - - / - - 10/ D. Tu Di mmer Zone 2	Gui de		
CLR/ Sl eep/ 12	Pr e Ch		