Original	Replacement	Original	Replacement
Power	Power	Menu	Menu
Mute	Mute	CH +	Ch +
◳ / Key	Info	CH -	Ch -
TV / Video	AV	Vol +	Vol +
1	1	Vol -	Vol -
2	2	CH +	Up
3	3	CH -	Down
4	4	Vol +	Right
5	5	Vol -	Left
6	6	[≡◉]	Media
7	7	[≡] / [/≡] / [	Text
8	8	Red	Red
9	9	Green	Green
0	0	Yellow	Yellow
Recall	Pre Ch	Blue	Blue
Recall	Back	[≡↕]	3D
-/--	Guide	[≡?]	Options

Original		Replacement		Original	Replacement
	[≡□]		Stop		
	[≡]	PICTURE FORMAT	Format		
	[≡X]	CLEAR EXIT	Exit		
	[≡]	HOME SMART	Smart		
	[≡S]	AD SUBT	Subt		
LIST	List	DISC NAV LIST	List		
LIST	List	OK	Ok		