Original	Replacement	Original	Replacement
TV Direct	Smart / List	Dimmer	Shift + Mute / Dimmer
Power DVD	Red / Netflix / Search	Sleep	Sleep / Timer
Power VCR	Green / APP / Repeat	Analog/Digital Input	AV / Input / RDS
Power Audio	Power	Smart S Setup	Setup / OPT /
Power STB	Yellow / YouTube / Repeat	Bass Boost	Audio / Lang I/II
Power TV	Blue / Prime Video / Random	C. Tone	Subtitle / EQ
DVD	2	A. Position	D.Menu / Top
VCR	4	Test Tone	Text / Goto
TV	1	Effect	Info / Angle
FM/AM	6	Decode	TV/Radio /
Tv/Video	5	Surround	Eject / Surround
Muting	Mute / Dimmer	Subwfr+	Right
Channel +	CH+ / Page+	Center+	Up
Volume+	Vol +	Surr L+	Shift + Vol +
Channel -	CH- / Page-	Surr R+	Shift + CH+ /
Volume-	Vol -	Subwfr-	Left
Display/On Screen	Display / Media	Center-	Down

Original	Replacement	Original	Replacement
Surr L-	SHIFT + VOL – Shift + Vol -		
Surr R-	SHIFT + CH PAGE – Shift + CH- /		

Original	Replacement
Power Audio	Power
Power Tv	SHIFT + Power
FM/AM	SURROUND Eject / Surround
Tv Vol +	VOL + Vol +
Channel + TV	CH + / Page+
Tv Vol -	VOL - Vol -
Channel - TV	CH - / Page-
Tuning- FM/AM	TUNE- << / Tune-
FM Mode FM/AM	LIST SMART Smart / List
Tuning+ FM/AM	TUNE+ >> / Tune+
Memory FM/AM	HOME MENU Menu / Home
TA/News/Info	ANGLE INFO Info / Angle
TA/News/Info	Up
PTY- FM/AM	Left
PTY+ FM/AM	Right
PTY Search	Down
PTY Search	NETFLIX SEARCH Red / Netflix / Search

Original	Replacement
Display FM/AM	MEDIA DISPLAY Display / Media
1 FM/AM	SHIFT + TV 1 Shift + 1
1 TV	TV 1 1
2 FM/AM	SHIFT + DVD 2 Shift + 2
2 TV	DVD 2 2
3 FM/AM	SHIFT + CD-STB 3 Shift + 3
3 TV	CD-STB 3 3
4 FM/AM	SHIFT + VIDEO 4 Shift + 4
4 TV	VIDEO 4 4
5 FM/AM	SHIFT + TAPE 5 Shift + 5
5 TV	TAPE 5 5
6 FM/AM	SHIFT + TUNER 6 Shift + 6
6 TV	TUNER 6 6
7 FM/AM	SHIFT + AUX-HDD 7 Shift + 7
7 TV	AUX-HDD 7 7
8 FM/AM	SHIFT + USB 8 Shift + 8
8 TV	USB 8 8

Original		Replacement		Original	Replacement
9	9 FM/AM	SHIFT + 9	Shift + 9		
9	9 TV	9	9		
TV RETURN 10	10 FM/AM	SHIFT + FAV MARKER	Shift + Fav / Marker / PC		
TV RETURN 10	10/Tv Return TV	SHIFT + 0	Shift + 0		
0	0 TV	0	0		
100+ +10	+10/100+	SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--		
100+ +10	+10 TV	FAV MARKER	Fav / Marker / PC		

Original		Replacement	
	Power DVD		Power
	I <<	PRESET-	I << / Preset-
	Play	SLOW	Play / Slow
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Top Menu	TOP MENU D.MENU	D.Menu / Top
	>>	TUNE+	>> / Tune+
	Up		Up
	Menu	HOME MENU	Menu / Home
	Left	SHIFT +	Shift + Left
	Enter	OK	OK
	Right		Right
	Set Up	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
	On Screen	SHIFT + MEDIA DISPLAY	Shift + Display / Media

Original		Replacement	
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	Title Group	SHIFT + TITLE SOUND	Shift + Sound / Title
	Return	RETURN BACK	Back / Return
	DVD Zoom	SIZE ZOOM	Zoom / Size
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	VFP Progressive	LIST SMART	Smart / List
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	←		Left
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	Angle	ANGLE INFO	Info / Angle

Original		Replacement		Original	Replacement
TV RETURN 10	10	GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
100+ +10	+10	PC FAV MARKER	Fav / Marker / PC		
DIMMER	Display/Dimmer	MEDIA DISPLAY	Display / Media		
ANALOG/DIGITAL INPUT	Input Analog/Digital	RDS AV INPUT	AV / Input / RDS		
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
EFFECT	HDD Sound Effect	TITLE SOUND	Sound / Title		
SURROUND	Surround	SURROUND	Eject / Surround		

Original	Replacement
Power VCR	SHIFT + Power (Shift + Power)
Power STB	Power
VCR	SHIFT + GUIDE EPG (Shift + Guide / EPG / -/--)
Muting	DIMMER MUTE (Mute / Dimmer)
Channel +	CH+ / Page+
Volume+	Vol +
Channel -	CH- / Page-
Volume-	Vol -
Play VCR	SLOW (Play / Slow)
<< VCR	TUNE- (<< / Tune-)
Stop/Memory	HOLD (Stop / Hold)
Pause VCR	STEP-FREEZE (Pause / Step / Freeze)
>> VCR	TUNE+ (>> / Tune+)
1 VCR	SHIFT + TV 1 (Shift + 1)
1 STB	TV 1 (1)
2 VCR	SHIFT + DVD 2 (Shift + 2)
2 STB	DVD 2 (2)

Original	Replacement
3 VCR	SHIFT + CD-STB 3 (Shift + 3)
3 STB	CD-STB 3 (3)
4 VCR	SHIFT + VIDEO 4 (Shift + 4)
4 STB	VIDEO 4 (4)
5 VCR	SHIFT + TAPE 5 (Shift + 5)
5 STB	TAPE 5 (5)
6 VCR	SHIFT + TUNER 6 (Shift + 6)
6 STB	TUNER 6 (6)
7 VCR	SHIFT + AUX-HDD 7 (Shift + 7)
7 STB	AUX-HDD 7 (7)
8 VCR	SHIFT + USB 8 (Shift + 8)
8 STB	USB 8 (8)
9 VCR	SHIFT + BLUETOOTH 9 (Shift + 9)
9 STB	BLUETOOTH 9 (9)
+10 TV	GUIDE EPG (Guide / EPG / -/--)
0 VCR	SHIFT + HDMI-SAT 0 (Shift + 0)
0 STB	HDMI-SAT 0 (0)