Mandis shop

Yamaha RAX21

Original		Replacement	
	Power		Power
	i Pod	1	1
	CD	2	2
	USB	3	3
	FM	4	4
	Phono	5	5
	AUX	6	6
	Preset Up	CH +	Ch +
	Preset Down	CH –	Ch -
	Tuning Up	>>	>>
	Tuning Down	<<	<<
	Memory	REC MODE	Rec
	Repeat	REPEAT TEXT	Text
	Stop		Stop
	Random	APP MEDIA	Media
	iPod Menu Sel Up		Up
	iPod Menu Sel Down		Down

Original		Replacement	
	Menu	TOP MENU MENU	Menu
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
	I <<		I <<
	Enter	OK	Ok
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
	Tone/Balance		Right
	Tone/Balance		Left
	Tone/Balance	HOME SMART	Smart
	Display	DISPLAY INFO	Info
	Dimmer	AD SUBT	Subt
	Sleep	PROG SLEEP	Sleep
	Pure Direct	SETTINGS OPT	Options