Mandis shop

Mitsubishi EX320U

Original	Replacement	Original	Replacement
POWER	Power		
Freeze	Mode		
MENU / EXIT	Menu		
AUTO	Auto		
UP / KEYSTONE	Up		
DOWN / KEYST.	Down		
LEFT	Left		
ENTER / MODE	Enter		
RIGHT / LOCK	Right		
Blank	Blank / Mute		
SOURCE	Source		
VOLUME+	Vol + / Page +		
VOLUME-	Vol - / Page -		
Magnify +	+ / Play		
Magnify -	- / Stop		
TIMER ON	Freeze / Timer		
TIMER SET UP	Shift + Freeze / Timer		

https://mandishop.eu/Mitsubishi/10425-603-replacement-remote-control-for-Mitsubishi-EX320U.htm