Original		Replacement	
STANDBY	Standby		Power
OPEN/CLOSE	Open / Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
GOTO	Goto	-/-- GUIDE	Guide
CLEAR	Add / Clear	CLEAR EXIT	Exit
<<	<<	<<	<<
>>	>>	>>	>>
II	Pause	II	Pause

Original		Replacement	
	Play	PLAY MODE	Play
	Stop		Stop
I<<	I<<	I<<	I<<
>>I	>>I	>>I	>>I
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
	Setup	SETTINGS OPT	Options
	Navigat	HOME SMART	Smart
TITLE	Title	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	PICTURE FORMAT	Format
SOURCE	Source	TIMER AV	AV
REC	Rec	REC MODE	Rec

Original	Replacement
Timer	SHIFT + TIMER AV — Shift + AV
Edit	APP MEDIA — Media
USB	A — Red
DVD	B — Green
HDD	C — Yellow
Disc Oper	E-MANUAL D.MENU — D. Menu
Slow	SHIFT + ⏸ — Shift + Pause
Return	RETURN BACK — Back
Repeat	REPEAT TEXT — Text
Zoom	SHIFT + ZOOM — Shift + Eject
CH+	+ CH — Ch +
CH-	CH − — Ch -
P/N	SEARCH TV/R — TV/R
Audio	SOUND DUAL — Dual
Vol +	+ VOL — Vol +
I/P	DISPLAY INFO — Info
Mute	MUTE — Mute

Original	Replacement
Vol -	VOL − — Vol -