Mandis shop

EUR643800

Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
AUX	AUX	TIMER AV	AV
TUNER/BAND	TUNER / BAND	HOME SMART	Smart
PRES	Preset Down	CH –	Ch -
ESET	Preset Up	+ CH	Ch +
PROGRAM	CD Program	SHIFT + PROG SLEEP	Shift + Sleep
CANCEL	CD Cancel	CLEAR EXIT	Exit
REPEAT	CD Repeat	REPEAT TEXT	Text
	CD I <<		I <<
	CD >>I		>>I
	CD Play	PLAY MODE	Play
	CD Pause		Pause
/CD	CD Stop / CD		Stop
DECK 1/2	TAPE Deck 1/2	OK	Ok
	TAPE <<		<<
	TAPE >>		>>

Original		Replacement	
	TAPE Play Rev.		Left
	TAPE Play		Right
	TAPE Stop		Down
REC PAUSE	TAPE Rec Pause	REC MODE	Rec
ON/FLAT	EQ SPACE On/Flat	TOP MENU MENU	Menu
MODE	EQ SPACE Mode	DISPLAY INFO	Info
MUTING -20 dB	Muting -20 dB	MUTE	Mute
– VOLU	Volume-	VOL –	Vol -
UME +	Volume+	+ VOL	Vol +

https://mandisshop.com/Panasonic/1655-970-replacement-remote-control-for-Panasonic-EUR643800.htm