Original	Replacement	Original	Replacement
Power	Power	Vol -	Vol -
1	1	Vol +	Vol +
2	2	TV / Video	TV/R
3	3	P. Mode	Format
4	4	S. Mode	Dual
5	5	Pre-CH	Pre Ch
6	6	Sleep	Sleep
7	7	Clear	Exit
8	8	P. Size	Eject
9	9	<< REW	<<
0	0	Play	Play
+100	Guide	>> FF	>>
Display	Info	Pause	Pause
Mute	Mute	Stop	Stop
Menu	Menu	TRK Up	>>I
CH+	Ch +	TRK Up	Up
CH-	Ch -	TRK Down	I <<

Original		Replacement		Original		Replacement	
	TRK Down		Down				
	Still		Ok				