Original		Replacement	
	Power		Power
AUX	AUX	A	Red
DIGITAL	Digital	D	Blue
	Bluetooth	B	Green
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
	I <<		I <<
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -

Original	Replacement