Mandis shop

RCT200DV

Original	Replacement
Power	Power
Open/Close	Eject
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Audio	Dual
(.....)	Subt
Movie	Smart
Menu	Menu

Original	Replacement
Title	Media
(¨¨¨¨)	TV/R
Exit	Exit
>>	>>
<<	<<
Play	Play
OK	Ok
>	Right
<	Left
Up	Up
Down	Down
>>I	>>I
I <<	I <<
Stop	Stop
Repeat	Text
Pause	Pause
Index	List

https://mandisshop.ie/en/10207-124-replacement-remote-control-for-RCT200DV35550.htm