| Original | Replacement |
|---|---|
| Standby | SHIFT + Power |
| Power | Power |
| Phono | SHIFT + 5 |
| Multi CH In | SHIFT + 0 |
| V-AUX/Dock | SHIFT + 7 |
| Tuner | SHIFT + 6 |
| MD/CD-R | SHIFT + 8 |
| CD | SHIFT + 3 |
| DTV/CBL | SHIFT + 1 |
| DVR | SHIFT + 9 |
| VCR | SHIFT + 4 |
| DVD | SHIFT + 2 |
| Vol + | Vol + |
| Vol - | Vol - |
| Mute | Mute / Dimmer |
| Level | Text / Goto |
| Title | Sound / Title |

| Original | Replacement |
|---|---|
| Up | Up |
| Menu | Menu / Home |
| Audio | Audio / Lang I/II |
| Left | Left |
| Enter | OK |
| Right | Right |
| Pure Direct | Setup / OPT / |
| Return | Back / Return |
| Down | Down |
| Display | Display / Media |
| Straight | D. Menu / Top |
| Classical | 1 |
| Live Club | 2 |
| Entertain | 3 |
| Movie | 4 |
| Stereo | 5 |
| Enhancer | 6 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| SUR. DECODE 7 | Sur. Decode | AUX - HDD 7 | 7 | | |
| NIGHT 8 | Night | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| SLEEP ENT | Sleep | TIMER SLEEP | Sleep / Timer | | |

| Original | Replacement |
|---|---|
| Standby | SHIFT + Power |
| Power | Power |
| Volume + | Vol + |
| Volume - | Vol - |
| Mute | Mute / Dimmer |
| Band | Red / Netflix / Search |
| Up | Up |
| Menu | Menu / Home |
| Left | Left |
| Enter | OK |
| Right / A/B/C/D/ | Right |
| Return | Back / Return |
| Down | Down |
| Display | Display / Media |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |

| Original | Replacement |
|---|---|
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| Sleep | Sleep / Timer |
| ENT | Fav / Marker / PC |
| Freq/Text | Green / APP / Repeat |
| EON | Guide / EPG / -/-- |
| PTY Seek Mode | Yellow / YouTube / Repeat |
| PTY Seek Start | Blue / Prime Video / Random |

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| + VOLUME | Vol + | + VOL | Vol + |
| VOLUME – | Vol - | VOL – | Vol - |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| LEVEL TITLE BAND | Title | TITLE SOUND | Sound / Title |
| PRESET/CH ▲ | Up | ▲ | Up |
| SET MENU MENU | Menu | HOME MENU | Menu / Home |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| ◄ | Left | ◄ | Left |
| ENTER | Enter | OK | OK |
| ► A/B/C/D/E | Right | ► | Right |
| RETURN | Return | RETURN BACK | Back / Return |
| ▼ | Down | ▼ | Down |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| CLASSICAL 1 | 1 | TV 1 | 1 |
| LIVE/CLUB 2 | 2 | DVD 2 | 2 |
| ENTERTAIN 3 | 3 | CD - STB 3 | 3 |

| Original | | Replacement | |
|---|---|---|---|
| MOVIE 4 | 4 | VIDEO 4 | 4 |
| STEREO 5 | 5 | TAPE 5 | 5 |
| ENHANCER 6 | 6 | TUNER 6 | 6 |
| SUR. DECODE 7 | 7 | AUX - HDD 7 | 7 |
| NIGHT 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| +10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| SLEEP ENT | ENT | PC FAV MARKER | Fav / Marker / PC |
| ◄◄ | << | TUNE- ◄◄ | << / Tune- |
| ►► | >> | TUNE+ ►► | >> / Tune+ |
| ►◄ | I << | PRESET- ►◄ | I << / Preset- |
| ►►I | >>I | PRESET+ ►►I | >>I / Preset+ |
| REC FREQ/TEXT | Rec | REC MODE ● | Rec / Rec Mode |
| EON ■ | Stop | HOLD ■ | Stop / Hold |
| MODE – PTY S ❚❚ | Pause | STEP - FREEZE ❚❚ | Pause / Step / Freeze |
| SEEK – START ► | Play | SLOW ► | Play / Slow |

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| + VOLUME | Volume+ | + VOL | Vol + |
| VOLUME – | Volume- | VOL – | Vol - |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| LEVEL TITLE BAND | Title | TITLE SOUND | Sound / Title |
| PRESET/CH ▲ | Up | ▲ | Up |
| SET MENU MENU | Menu | HOME MENU | Menu / Home |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| ◀ | Left | ◀ | Left |
| ENTER | Enter | OK | OK |
| ▶ A/B/C/D/E | Right | ▶ | Right |
| RETURN | Return | RETURN BACK | Back / Return |
| ▼ | Down | ▼ | Down |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| CLASSICAL 1 | 1 | TV 1 | 1 |
| LIVE/CLUB 2 | 2 | DVD 2 | 2 |
| ENTERTAIN 3 | 3 | CD - STB 3 | 3 |

| Original | | Replacement | |
|---|---|---|---|
| MOVIE 4 | 4 | VIDEO 4 | 4 |
| STEREO 5 | 5 | TAPE 5 | 5 |
| ENHANCER 6 | 6 | TUNER 6 | 6 |
| SUR. DECODE 7 | 7 | AUX - HDD 7 | 7 |
| NIGHT 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| +10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| SLEEP ENT | ENT | PC FAV MARKER | Fav / Marker / PC |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| ⏮ | I << | PRESET- ⏮ | I << / Preset- |
| ⏭ | >>I | PRESET+ ⏭ | >>I / Preset+ |
| REC FREQ/TEXT | Rec | REC MODE ● | Rec / Rec Mode |
| EON ■ | Stop | HOLD ■ | Stop / Hold |
| MODE – PTY S ❚❚ | Pause | STEP - FREEZE ❚❚ | Pause / Step / Freeze |
| SEEK – START ▶ | Play | SLOW ▶ | Play / Slow |