Original		Replacement	
ON	Power On		Power
OFF	Power Off	SHIFT +	Shift + Power
Mute	Mute	MUTE	Mute
Stereo	Stereo	SHIFT + SOUND DUAL	Shift + Dual
Cable/Sat	Cable/Sat	B	Green
TV	TV	D	Blue
CD	CD	C	Yellow
MENU	Menu	TOP MENU MENU	Menu
Harman Volume	Harman Volume	HOME SMART	Smart
Exit	Exit	CLEAR EXIT	Exit
Tone Control	Tone Control	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
1	1	1	1

Original		Replacement	
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Clear	Clear	SHIFT + CLEAR EXIT	Shift + Exit
Direct	Direct	-/-- GUIDE	Guide
Vol	Vol+	+ VOL	Vol +
Vol	Vol-	VOL −	Vol -
CH/ Tuner	CH/Tuner Up	+ CH	Ch +
CH/ Tuner	CH/Tuner Down	CH −	Ch -
Speaker 1	Speaker 1	SETTINGS OPT	Options
Speaker 2	Speaker 2	SOUND DUAL	Dual

Original		Replacement	
Sleep	Sleep	PROG SLEEP	Sleep
DIM	Dim	SEARCH TV/R	TV/R
P-Scan	P.Scan	REPEAT TEXT	Text
A-Preset	A.Preset	TIMER AV	AV
MEM	MEM	PICTURE FORMAT	Format
RDS	RDS	AD SUBT	Subt
Prev.CH	Prev.CH	FAV PRE-CH	Pre Ch
I<	I<	K<	I<<
<<	<<	<<	<<
>>	>>	>>	>>
>I	>I	>>I	>>I
■	Stop	■	Stop
▶	Play	PLAY MODE ▶	Play
II	Pause	II	Pause
Phono	Phono	SHIFT + 1	Shift + 1
FM/AM	FM/AM	SHIFT + 2	Shift + 2
USB	USB	SHIFT + 3	Shift + 3

Original		Replacement	
Bluetooth	Bluetooth	SHIFT + 4	Shift + 4
vTuner	vTuner	SHIFT + 5	Shift + 5
Network	Network	SHIFT + 6	Shift + 6
AUX	AUX	SHIFT + 7	Shift + 7
Digital	Digital	SHIFT + 8	Shift + 8

Original		Replacement	
ON	Power On		Power
OFF	Power Off	SHIFT +	Shift + Power
	Left		Left
	Right		Right
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Vol	Vol+ Stereo	+ VOL	Vol +
Vol	Vol- Stereo	VOL −	Vol -
Stereo	Stereo	SOUND DUAL	Dual

Original		Replacement	
Cable/Sat	Cable/Sat	B	Green
CD	CD	C	Yellow
TV	TV	D	Blue
Mute	Mute	MUTE	Mute

Original		Replacement	
ON	Power On		Power
OFF	Power Off	SHIFT +	Shift + Power
Mute	Mute	MUTE	Mute
Stereo	Stereo	SHIFT + SOUND DUAL	Shift + Dual
Cable/Sat	Cable/SAT	B	Green
TV	TV	D	Blue
CD	CD	C	Yellow
MENU	Menu	TOP MENU MENU	Menu
Harman Volume	Harman Volume	HOME SMART	Smart
Exit	Exit	CLEAR EXIT	Exit
Tone Control	Tone Control	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
1	1	1	1

Original		Replacement	
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Clear	Clear	SHIFT + CLEAR EXIT	Shift + Exit
Direct	Direct	-/-- GUIDE	Guide
Vol	Vol+ Stereo	+ VOL	Vol +
Vol	Vol- Stereo	VOL −	Vol -
CH/ Tuner	CH/Tuner Down	+ CH	Ch +
CH/ Tuner	CH/Tuner Up	CH −	Ch -
Speaker 1	Speaker 1	SETTINGS OPT	Options
Speaker 2	Speaker 2	SOUND DUAL	Dual

Original		Replacement	
Sleep	Sleep	PROG SLEEP	Sleep
DIM	DIM	SEARCH TV/R	TV/R
P-Scan	P.Scan	REPEAT TEXT	Text
A-Preset	A.Preset	TIMER AV	AV
MEM	MEM	PICTURE FORMAT	Format
RDS	RDS	AD SUBT	Subt
Prev.CH	Prev.CH	FAV PRE-CH	Pre Ch
I<	I<	K<	I<<
<<	<<	<<	<<
>>	>>	>>	>>
>I	>I	>>I	>>I
Stop	Stop	Stop	Stop
Play	Play	PLAY MODE Play	Play
Pause	Pause	Pause	Pause

Original	Replacement