Original		Replacement	
	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
SUBTITLE POSITION MEMORY	Subtitle	EQ SUBTITLE	Subtitle / EQ
SUBTITLE POSITION MEMORY	Position	NETFLIX SEARCH	Red / Netflix / Search
SETUP GROUP	Group	APP REPEAT	Green / APP / Repeat
SETUP GROUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
DISC	Disc	REC MODE	Rec / Rec Mode
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
≧10/-/--	>=10 / -/--	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Replacement	
0	0	HDMI - SAT 0	0
PRO LOGIC	DD Pro Logic	LIST SMART	Smart / List
CH SELECT TEST	CH Select	PC FAV MARKER	Fav / Marker / PC
CH SELECT TEST	Test	GOTO TEXT	Text / Goto
SUPER SRND	Super SRND	SURROUND	Eject / Surround
TOP MENU EQ DIRECT NAVIGATOR	Top Menu / Direct Navigator	TOP MENU D.MENU	D.Menu / Top
TOP MENU EQ DIRECT NAVIGATOR	EQ	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ
	Up		Up
MENU SUPER SOUND EQ PLAY LIST	Menu/Playlist	HOME MENU	Menu / Home
MENU SUPER SOUND EQ PLAY LIST	Super Surround	TITLE SOUND	Sound / Title
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
S.3D AI EQ DISPLAY	Display	MEDIA DISPLAY	Display / Media
S.3D AI EQ DISPLAY	Super 3D AI EQ	FORMAT PICTURE	Picture / Format
	Down		Down
AV EFFECT RETURN	AV Effect	RDS AV INPUT	AV / Input / RDS

Original		Replacement	
RETURN	Return	RETURN / BACK	Back / Return
VCR/EXT / VDP/AUX	VCR (Ext) / VDP (Aux)	SHIFT + VIDEO 4	Shift + 4
TAPE / DECK 1/2	TAPE / Deck 1/2	SHIFT + TAPE 5	Shift + 5
DVD	DVD	SHIFT + DVD 2	Shift + 2
TUNER / BAND	TUNER / BAND	SHIFT + TUNER 6	Shift + 6
CANCEL / PLAY MODE	Play Mode	SHIFT + SLOW ▶	Shift + Play /
CANCEL / PLAY MODE	Cancel	CLEAR / EXIT / CANCEL	Exit / Cancel / Clear
◀/II	Rev. Play / Pause	STEP-FREEZE II	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
▶	Play	SLOW ▶	Play / Slow
MIX 2CH / AUDIO	Audio	LANG I/II / AUDIO	Audio / Lang I/II
MIX 2CH / AUDIO	Mix 2CH	PROGRAM / TV/RADIO	TV/Radio /
DIGITAL S.WOOFER	Digital S.Woofer	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
◀◀ SLOW/SE	<< Slow/Search	TUNE- ◀◀	<< / Tune-
/SEARCH ▶▶	Slow/Search >>	TUNE+ ▶▶	>> / Tune+
MUTING	Muting	DIMMER / MUTE	Mute / Dimmer
⏮ SK	I<< Skip	PRESET- ⏮	I<< / Preset-

Original		Replacement	
SKIP ▶▶I	Skip >>I	PRESET+ ▶▶I	>>I / Preset+
VOLUME-	Volume-	VOL −	Vol-
VOLUME+	Volume+	VOL +	Vol+