Original	Replacement	Original	Replacement
Mute	Mute / Dimmer	[>I <]	Display / Media
Power Video	Shift + Power	CH-	Shift + CH- /
Power	Power	Stop	Stop / Hold
[ ]	Picture / Format	Pause	Pause / Step / Freeze
[i +]	Info / Angle	Rec	Rec / Rec Mode
→ ←	Smart / List	1	1
[⏲]	Sleep / Timer	2	2
Text	Text / Goto	3	3
◨ / ◳	Setup / OPT /	4	4
Input	AV / Input / RDS	5	5
[I]	Shift + Guide / EPG / -/--	6	6
◳ / ◨	D. Menu / Top	7	7
↑	Zoom / Size	8	8
<<	<< / Tune-	9	9
Play	Play / Slow	-/--	Guide / EPG / -/--
>>	>> / Tune+	0	0
CH+	Shift + CH+ / Page+	Recall	Back / Return

Original	Replacement	Original	Replacement
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Up	Up		
Left	Left		
OK	OK		
Right	Right		
Down	Down		
Vol +	Vol +		
Progr +	CH+ / Page+		
Menu	Menu / Home		
Vol -	Vol -		
Progr -	CH- / Page-		

Original		Replacement		Original	Replacement
	Power Video		Power		
	→ ←		Smart / List		
	[O]		Sleep / Timer		
	<<		<< / Tune-		
	Play		Play / Slow		
	>>		>> / Tune+		
	CH+		CH+ / Page+		
	CH-		CH- / Page-		
	Stop		Stop / Hold		
	Pause		Pause / Step / Freeze		
	Rec		Rec / Rec Mode		

Original	Replacement	Original	Replacement
Power Video	Power		
→ ←	Smart / List		
[O]	Sleep / Timer		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
CH+	CH+ / Page+		
CH-	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		

Original	Replacement	Original	Replacement
Power Video	Power		
→ ←	Smart / List		
[O]	Sleep / Timer		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
CH+	CH+ / Page+		
CH-	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		