Original	Replacement
Power Source	Shift + Power
Power Receiver	Power
HDMI 1	Shift + 1
HDMI 2	Shift + 2
HDMI 3	Shift + 3
HDMI 4	Shift + 4
HDMI 5	Shift + 5
V-AUX	AV / Input / RDS
AV 1	Shift + 6
AV 2	Shift + 7
AV 3	Shift + 9
AV 4	Shift + Guide / EPG / -/--
AV 5	Shift + 0
AV 6	Shift + Fav / Marker / PC
Audio	Audio / Lang I/II
Dock	Eject / Surround
TUNER	TV/Radio / Program

Original	Replacement
PHONO	Subtitle / EQ
Net	Shift + AV / Input / RDS
USB	Shift + 8
FM	Smart / List
AM	Shift + Smart / List
Presset Up	Shift + >>I / Preset+
Presset Up	CH+ / Page+
Tunning Up	Shift + >> /
Info	Info / Angle
Memory	Text / Goto
Preset Down	Shift + I<< / Preset-
Preset Down	CH- / Page-
Tuning Down	Shift + << /
Movie	Shift + Left
Music	Shift + Up
Sur. Decode	Shift + OK
Straight	Shift + Right

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ENHANCER	Enhancer	SHIFT + ▼	Shift + Down
PURE DIRECT	Direct	SHIFT + ANGLE INFO	Shift + Info / Angle
BD DVD	Scene BD/DVD	NETFLIX SEARCH	Red / Netflix / Search
TV	Scene TV	APP REPEAT	Green / APP / Repeat
CD	Scene CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RADIO	Scene Radio	Prime Video RANDOM	Blue / Prime Video / Random
ON SCREEN	On Screen	FORMAT PICTURE	Picture / Format
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
VOLUME +	Vol +	+ VOL	Vol +
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
VOLUME −	Vol -	VOL −	Vol -
RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down

Original		Replacement	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top
POP-UP MENU	Pop-Up Menu	HOME MENU	Menu / Home
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
MODE	Mode	REC MODE	Rec / Rec Mode
■	Stop	HOLD ■	Stop / Hold
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
▶	Play	SLOW ▶	Play / Slow
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I <<	PRESET- ⏮	I << / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Replacement		Original	Replacement
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
ENT	ENT	PC FAV MARKER	Fav / Marker / PC		

Original	Replacement	Original	Replacement
Power Receiver	Power	Net	Picture / Format
HDMI 1	Shift + 1	USB	Shift + 8
HDMI 2	Shift + 2	FM	Smart / List
HDMI 3	Shift + Yellow / YouTube /	AM	Yellow / YouTube / Repeat
HDMI 4	Shift + 4	Preset Up	Shift + >>I / Preset+
HDMI 5	Shift + 5	Tuning Up	CH+ / Page+
V-AUX	Shift + 7	Info	Info / Angle
AV 1	Shift + Red / Netflix /	Memory	Rec / Rec Mode
AV 2	Shift + Green / APP /	Preset Down	Shift + I<< / Preset-
AV 3	Shift + 9	Tuning Down	CH- / Page-
AV 4	Shift + Guide / EPG / -/--	Sleep	Sleep / Timer
AV 5	Shift + 0	Scene BD/DVD	Red / Netflix / Search
AV 6	Shift + Fav / Marker / PC	Scene TV	Green / APP / Repeat
Audio	Audio / Lang I/II	Scene CD	Shift + 3
Dock	Text / Goto	Scene Radio	TV/Radio /
Tuner	Shift + 6	Volume+	Vol +
Phono	AV / Input / RDS	Up	Up

Original		Replacement	
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
VOLUME	Volume-	VOL	Vol -
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top
POP-UP MENU	Pop-Up Menu	HOME MENU	Menu / Home
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
MODE	Mode	SIZE ZOOM	Zoom / Size
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I <<	PRESET-	I << / Preset-

Original		Replacement	
	>>I	PRESET+	>>I / Preset+
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
ENT	ENT	PC FAV MARKER	Fav / Marker / PC