Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
PMODE	P. Mode	SHIFT + PICTURE FORMAT	Shift + Format
S.MODE	S. Mode	SHIFT + SOUND DUAL	Shift + Dual
NICAM/A2	Nicam / A2	SOUND DUAL	Dual
SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/-- GUIDE	Guide

Original		Replacement	
	Recall	FAV PRE-CH	Pre Ch
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
FAV+	Fav +	SHIFT + ▲	Shift + Up
FAV-	Fav -	SHIFT + ▼	Shift + Down
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
SOURCE	Source	TIMER AV	AV
INFO	Info	DISPLAY INFO	Info
▲	Up	▲	Up
▶	Right	▶	Right
▼	Down	▼	Down
◀	Left	◀	Left
OK	OK	OK	Ok
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit

Original	Replacement
Vol +	Vol +
Vol -	Vol -
Media	Media
TV / Radio	TV/R
CH +	Ch +
CH -	Ch -
Play/Pause / Tex	Play
Play/Pause / Tex	Pause
Play/Pause / Tex	Text
<< / Size	<<
<< / Size	3D
>> / Reveal	>>
Stop / Hold	Stop
I << / Index	I <<
>>I / Subpage	>>I
Cancel	SHIFT + CLEAR EXIT Shift + Exit
Subtitle	Subt

Original	Replacement
Rec	SHIFT + REPEAT TEXT Shift + Text
Timeshift	Smart
A-B	Back
EPG	Format