Original		Replacement	
	Power		Power
	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
MUTE	Mute	MUTE	Mute
SUBTL	Subtl	AD SUBT	Subt
V+	Vol +	+ VOL	Vol +
V-	Vol -	VOL −	Vol -
	- I SI -	SHIFT + SOUND DUAL	Shift + Dual

Original		Replacement	
	- I PI -	SHIFT + PICTURE FORMAT	Shift + Format
P+	P+	+ CH	Ch +
P-	P-	CH −	Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK SELECT	OK/Select	OK	Ok
DTV MENU	DTV Menu	E-MANUAL D.MENU	D. Menu
CALL	Call	FAV PRE-CH	Pre Ch
ATV MENU	ATV Menu	TOP MENU MENU	Menu
SLEEP	Sleep	PROG SLEEP	Sleep
EXIT I/II	Exit	CLEAR EXIT	Exit
EXIT I/II	I/II	SOUND DUAL	Dual
QV	QV	ECO 3D	3D
EPG	EPG	-/-- GUIDE	Guide
PAGE+	Page+		>>

Original		Replacement	
PAGE-	Page-	<<	<<
INFO	Info	DISPLAY INFO	Info
TEXT	Text	REPEAT TEXT	Text
MIX	Mix	SEARCH TV/R	TV/R
SIZE	[II]/Size	PICTURE FORMAT	Format
INDEX	Index	DISC NAV LIST	List
HOLD	Hold	APP MEDIA	Media
REVEAL	Reveal	SETTINGS OPT	Options
CANCEL	Cancel	RETURN BACK	Back
SUBPAGE	Subpage	ZOOM ⏏	Eject
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue

Original	Replacement