Mandis shop

RMT- 234

Original		Replacement	
ON	Power		Power
PROGRAM +	Program+	CH +	Ch +
PROGR	Program-	CH −	Ch -
REC	Rec	REC MODE	Rec
PLAY	Play	PLAY MODE	Play
FF	>>		>>
REW	<<		<<
STOP	Stop		Stop
PAUSE	Pause		Pause

Original	Replacement

https://mandisshop.tv/Sony-1063209-replacement-remote-control-for-Sony-RMT-234-163852.htm