Mandis shop

JVC HR-D300

Original		Replacement		Original	Replacement
	Power		Power		
	TV PR-	CH PAGE	CH- / Page-		
	PR-		Left		
	TV P-		Down		
	TV PR+	CH PAGE	CH+ / Page+		
	PR+		Right		
	TV P+		Up		
	<<	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
	>>	TUNE+	>> / Tune+		
	Rec	REC MODE	Rec / Rec Mode		
	Stop	HOLD	Stop / Hold		
	Pause	STEP - FREEZE	Pause / Step / Freeze		

https://mandisshop.ie/en/JVC/1065143-95721-replacement-remote-control-for-JVC-HR-D300.html