Original		Replacement	
	Power		Power
	TV	SHIFT + TV 1	Shift + 1
	Caption	EQ SUBTITLE	Subtitle / EQ
	AV Mode	SURROUND	Eject / Surround
	[ ]/Ratio	PROGRAM TV/RADIO	TV/Radio /
	Input	RDS AV INPUT	AV / Input / RDS
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	List	LIST SMART	Smart / List
	0	HDMI-SAT 0	0

Original		Replacement	
	Flashbk	GOTO TEXT	Text / Goto
	Vol +	VOL +	Vol +
	FAV	PC FAV MARKER	Fav / Marker / PC
	CH/Page-	CH PAGE −	CH- / Page-
	CH/Page+	CH PAGE +	CH+ / Page+
	Vol -	VOL −	Vol -
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Mute	DIMMER MUTE	Mute / Dimmer
	Picture	FORMAT PICTURE	Picture / Format
	Info	ANGLE INFO	Info / Angle
	Sound	TITLE SOUND	Sound / Title
	Settings	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
	Q.Menu	TOP MENU D.MENU	D.Menu / Top
	Left		Left
	OK	OK	OK
	Right		Right

Original		Replacement		Original	Replacement
BACK	Back	RETURN BACK	Back / Return		
▼	Down	▼	Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
SIMPLINK	Simplink	MEDIA DISPLAY	Display / Media		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
■	Stop	HOLD ■	Stop / Hold		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶	Play	SLOW ▶	Play / Slow		
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
●	Red	NETFLIX SEARCH	Red / Netflix / Search		
●●	Green	APP REPEAT	Green / APP / Repeat		
●●●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
●●●●	Blue	Prime Video RANDOM	Blue / Prime Video / Random		